

APTER POWER PRODUCT GUIDE

MV03

H&B Contronic Module

The ABB H&B Contronic MV03 is a legacy control-system module identified by the MV 03 hardware code. It is retained as a model-specific unit for the installed Contronic assembly.

Manufacturer	ABB
Model	MV03
Product type	H&B Contronic Module
Product family	H&B Contronic
Country	Sweden
HS code	8537101190
Shipping origin	Xiamen, Fujian, China

APTER POWER SALES TEAM

INDUSTRIAL AUTOMATION PRODUCT SUPPORT

Three interface paths, one controlled configuration.

WHATSAPP / PHONE +86 180 3023 5313
EMAIL sales13@apterpower.com



SCAN FOR PRODUCT & QUOTE

1. Product overview and identity

- Maintains the documented MV 03 position in the installed cabinet
- Preserves the original controller-to-module assignment
- Supports model-specific service work without changing the slot identity
- Keeps wiring and configuration aligned with the plant drawing set

Model configuration

Complete model	MV03
Product type	H&B Contronic Module
System family	H&B Contronic

2. Technical specifications

Model-controlled field verification

Use the complete model identity, installed carrier position, wiring schedule and controller configuration as the controlling technical records.

3. Functions, applications and components

MV03 cabinet-position retention

Maintains the documented MV 03 position in the installed cabinet

MV03 control-loop service

Preserves the original controller-to-module assignment

MV03 shutdown maintenance

Supports model-specific service work without changing the slot identity

MV03 engineered replacement planning

Keeps wiring and configuration aligned with the plant drawing set

Associated system components

- H&B Contronic carrier or rack
- installed terminal wiring
- controller configuration
- plant loop drawings

4. Engineering FAQ and source record

How should MV03 be identified before cabinet work?

Read the MV 03 front label, board revision and installed slot, then record all three in the job package.

What compatibility check is required for MV03?

Match MV03 to the original carrier position, connector keying and controller configuration.

How should wiring be handled when removing MV03?

Label every conductor and terminal position before disturbing the MV03 circuit.

What configuration should be retained for MV03?

Retain the slot assignment, loop references and controller database entry associated with MV03.

ASK FOR QUOTE

Contact sales13@apterpower.com or +86 180 3023 5313.