

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Bently Nevada

330101-30-60-10-02-05

Installation Guide

3300 XL 8 mm 3/8-24 UNF unarmored proximity probe

DOCUMENT SCOPE

Apter Power product reference prepared from product-specific Bently Nevada technical information. Confirm the complete product identity and installed-system requirements before use. No product photograph is included.

Product / lookup identity	Bently Nevada 330101-30-60-10-02-05
Reference number	330101-30-60-10-02-05
Document basis	Bently Nevada technical documents listed on page 3



Product page

<https://www.apterpower.com/Bently-Nevada/330101-30-60-10-02-05>
Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Bently Nevada 330101-30-60-10-02-05 is a 3300 XL 8 mm unarmored 3/8-24 UNF proximity probe with 3.0 in unthreaded length, 6.0 in case length, 1.0 m total length and multiple approvals. Use it only in the matched Bently Nevada machinery-monitoring installation and verify the complete product code, associated hardware, mounting and wiring before service.

01	System Inputs: 3300 XL 8 mm 3/8-24 UNF unarmored proximity probe
02	Processing: Bently Nevada 330101-30-60-10-02-05 is a 3300 XL 8 mm unarmored 3/8-24 UNF proximity probe with 3.0 in unthreaded length, 6.0 in case length, 1.0 m total length and multiple approvals.

Published context and boundaries

01	Use only with a matched 1 m 3300 XL system; confirm the complete label, target material, gap setting and certified installation arrangement before service.
02	Verify model 330101-30-60-10-02-05 and the complete order code on the physical label before use.
03	Match every 330101-30-60-10-02-05 connector, terminal, cable and companion assembly before moving field wiring.

Verification and release checks

01	Verify model 330101-30-60-10-02-05 and the complete order code on the physical label before use.
02	Use only with a matched 1 m 3300 XL system; confirm the complete label, target material, gap setting and certified installation arrangement before service.
03	Match every 330101-30-60-10-02-05 connector, terminal, cable and companion assembly before moving field wiring.
04	Back up the applicable controller, monitor, HMI or I/O configuration before replacing 330101-30-60-10-02-05.
05	Isolate energy and follow the approved site safety procedure before handling 330101-30-60-10-02-05.
06	Follow ESD controls and protect 330101-30-60-10-02-05 connectors and printed-circuit assemblies during handling.

Identity and release controls

Verification Status	Verified Product Reference
---------------------	----------------------------

Official Bently Nevada sources

3300 XL 8 mm Proximity Transducer System Datasheet	https://dam.bakerhughes.com/m/23d2a1de24360b13/original/3300-XL-8mm-Proximity-Transducer-System-Datasheet-141194-pdf.pdf
--	---