

MANUFACTURER-SOURCE TECHNICAL REFERENCE

Bently Nevada 200151-40-03-00

Installation Guide

accelerometer interface standard cable

DOCUMENT SCOPE

Apter Power product reference prepared from product-specific Bently Nevada technical information. Confirm the complete product identity and installed-system requirements before use. No product photograph is included.

Product / lookup identity	Bently Nevada 200151-40-03-00
Reference number	200151-40-03-00
Document basis	Bently Nevada technical documents listed on page 3



Product page

<https://www.apterpower.com/Bently-Nevada/200151-40-03-00>

Apter Power contact

sales13@apterpower.com | +86 180 3023 5313

Workflow and system context

Bently Nevada 200151-40-03-00 is a 4.0 m armored blue accelerometer-interface cable with connectors on both ends and standard coupling nuts. Use it only in the matched Bently Nevada machinery-monitoring installation and verify the complete product code, associated hardware, mounting and wiring before service.

- | | |
|----|--|
| 01 | System Inputs: accelerometer interface standard cable |
| 02 | Processing: Bently Nevada 200151-40-03-00 is a 4.0 m armored blue accelerometer-interface cable with connectors on both ends and standard coupling nuts. |

Published context and boundaries

- | | |
|----|---|
| 01 | Confirm cable length, connector engagement, armor routing, bend control and compatibility with the installed accelerometer before installation. |
| 02 | Verify model 200151-40-03-00 and the complete order code on the physical label before use. |
| 03 | Match every 200151-40-03-00 connector, terminal, cable and companion assembly before moving field wiring. |

Verification and release checks

01	Verify model 200151-40-03-00 and the complete order code on the physical label before use.
02	Confirm cable length, connector engagement, armor routing, bend control and compatibility with the installed accelerometer before installation.
03	Match every 200151-40-03-00 connector, terminal, cable and companion assembly before moving field wiring.
04	Back up the applicable controller, monitor, HMI or I/O configuration before replacing 200151-40-03-00.
05	Isolate energy and follow the approved site safety procedure before handling 200151-40-03-00.
06	Follow ESD controls and protect 200151-40-03-00 connectors and printed-circuit assemblies during handling.

Identity and release controls

Verification Status	Verified Product Reference
---------------------	----------------------------

Official Bently Nevada sources

200150, 200155 and 200157 Accelerometers Datasheet	https://dam.bakerhughes.com/m/205aecc925d18534/original/200150-200155-and-200157-Accelerometers-Datasheet-164986-pdf.pdf
--	---