

330101-00-19-10-02-00

3300 XL 8 mm Proximity Probe

Bently Nevada 330101-00-19-10-02-00 is a 3/8-24 UNF unarmored 3300 xl 8 mm proximity probe with a 1.0 m lead and Miniature coaxial ClickLoc connection. It senses shaft-to-bearing relative displacement in a matched proximity transducer system.

BRAND	Bently Nevada	FAMILY	Bently Nevada 3300 XL 8 mm Proximity Transducer System
PART	330101-00-19-10-02-00	SYSTEM ROLE	Detects shaft-to-bearing relative movement without mechanical contact

APTER POWER SALES
TEAM

WHATSAPP / PHONE
+86 180 3023 5313
EMAIL sales13@apterp
ower.com
WEBSITE
www.apterpower.com



330101-00-19-10-02-00

MANUFACTURER SOURCE RECORD

3300 XL 8 mm Proximity Transducer System Datasheet
Baker Hughes document 141194 Rev. AM

Product Overview

SYSTEM FUNCTION

Bently Nevada 330101-00-19-10-02-00 is a 3/8-24 UNF unarmored 3300 xl 8 mm proximity probe with a 1.0 m lead and Miniature coaxial ClickLoc connection. It senses shaft-to-bearing relative displacement in a matched proximity transducer system.

FUNCTION 1

Detects shaft-to-bearing relative movement without mechanical contact

FUNCTION 2

Forms the field sensing element of the matched eddy-current loop

FUNCTION 3

Carries the probe signal through the specified service connection

FUNCTION 4

Supports static-position and vibration measurements on rotating machinery

System Components

COMPONENT	DOCUMENTED ROLE
Host / carrier	Bently Nevada 3300 XL 8 mm Proximity Transducer System
Primary interface	Detects shaft-to-bearing relative movement without mechanical contact
Engineering context	Use 330101-00-19-10-02-00 only with its documented host, interfaces and accessories; record the as-found arrangement and complete a controlled functional verification after installation.
Commissioning duty	Prove polarity, static position, dynamic response and alarm action before returning the channel to service.

TECHNICAL NOTE

Install 330101-00-19-10-02-00 only in the documented Bently Nevada 3300 XL 8 mm Proximity Transducer System arrangement and record the exact connection and configuration before removal. Restore the approved settings, then verify diagnostics and functional response before release.

Technical Data

PARAMETER	VALUE	PARAMETER	VALUE
Country of origin	USA	Unthreaded length	0.0 in
HS code	8537101190	Case length	1.9 in
Complete order number	330101-00-19-10-02-00	Total lead length	1.0 m
Probe construction	Without armor	Frequency response	0 to 10 kHz, +0/-3 dB
Mounting thread	3/8-24 UNF	Probe cable impedance	75 ohm

Related Products on Apter Power

MODEL	SYSTEM ROLE	APTER POWER PAGE
330104-00-12-10-02-00	armored probe	View 330104-00-12-10-02-00 page
330104-03-06-10-02-00	armored probe	View 330104-03-06-10-02-00 page
330104-06-12-10-02-00	armored probe	View 330104-06-12-10-02-00 page
330105-02-12-10-02-05	reverse-mount probe	View 330105-02-12-10-02-05 page
330106-05-30-10-02-05	reverse-mount probe	View 330106-05-30-10-02-05 page
330130-080-00-00	extension cable	View 330130-080-00-00 page
330180-50-00	Proximitior Sensor	View 330180-50-00 page
3500/25	Keyphasor module	View 3500/25 page

ENGINEERING BOUNDARY

Confirm the complete 330101-00-19-10-02-00 marking, installed host, hardware execution, terminals or connectors, wiring, grounding, configuration, accessories and controlled commissioning results.

Applications and Precautions

Common Applications

Radial shaft-vibration measurement

Measures shaft motion relative to the bearing housing in a matched proximity loop.

Machine shaft centerline observation

Supplies slow-roll and static-position information for the configured monitor.

Axial position monitoring

Provides the field sensing point for a documented thrust-position channel.

Probe replacement in a matched loop

Restores the exact mechanical and cable execution without changing system identity.

Product Precautions

- 1

Confirm the complete 330101-00-19-10-02-00 marking, 3/8-24 UNF thread and 1.9 in case execution.
- 2

Place the monitored machine and associated protection channel in the approved maintenance state.
- 3

Protect the 8.0 mm probe tip and keep the mounting thread free from burrs and contamination.
- 4

Route the 1.0 m unarmored probe lead without sharp bends, crushing or tensile loading.
- 5

Keep the Miniature coaxial ClickLoc connection clean, dry and finger-tight.
- 6

Confirm the installed extension cable and Proximitor Sensor match the approved total system length.
- 7

Set the static gap within the documented linear region while maintaining target clearance.
- 8

Prove polarity, static position, dynamic response and alarm action before returning the channel to service.

IMPORTANT NOTICE

Confirm the complete 330101-00-19-10-02-00 marking, installed host, hardware execution, terminals or connectors, wiring, grounding, configuration, accessories and controlled commissioning results.

ACCEPTANCE CHECK	REQUIRED EVIDENCE
Identity	330101-00-19-10-02-00
Configuration	Set the static gap within the documented linear region while maintaining target clearance.
Functional release	Prove polarity, static position, dynamic response and alarm action before returning the channel to service.

Engineer FAQ

Q1 What makes 330101-00-19-10-02-00 the correct execution for this installation?

Confirm 330101-00-19-10-02-00, 3/8-24 UNF host thread, 0.0 in unthreaded length, 1.9 in case execution, without armor, Miniature coaxial ClickLoc, extension cable, Proximitor Sensor, total system length, target material, wiring, shielding, grounding, monitor configuration, static gap and controlled response-test results before commissioning.

Q3 Which companion components must remain matched to 330101-00-19-10-02-00?

The probe is fitted to the engineered 3/8-24 UNF machine position and connected to the selected extension cable and Proximitor Sensor. Commissioning includes order-code, clearance, cable-route, total-system-length, static-gap and controlled response checks.

Q5 How should the physical interface of 330101-00-19-10-02-00 be inspected?

Confirm the installed extension cable and Proximitor Sensor match the approved total system length.

Q7 Which commissioning observations prove 330101-00-19-10-02-00 is operating normally?

Confirm the complete 330101-00-19-10-02-00 marking, 3/8-24 UNF thread and 1.9 in case execution. Keep the Miniature coaxial ClickLoc connection clean, dry and finger-tight.

Q2 Where is 330101-00-19-10-02-00 used within the documented Bently Nevada 3300 XL 8 mm Proximity Transducer System architecture?

Detects shaft-to-bearing relative movement without mechanical contact. It senses shaft-to-bearing relative displacement in a matched proximity transducer system.

Q4 What pre-work evidence is needed before disconnecting 330101-00-19-10-02-00?

Place the monitored machine and associated protection channel in the approved maintenance state. Protect the 8.0 mm probe tip and keep the mounting thread free from burrs and contamination.

Q6 What configuration values must agree with the installed 330101-00-19-10-02-00?

Set the static gap within the documented linear region while maintaining target clearance.

Q8 What maintenance evidence closes the work on 330101-00-19-10-02-00?

Prove polarity, static position, dynamic response and alarm action before returning the channel to service.

MANUFACTURER SOURCE RECORD

3300 XL 8 mm Proximity Transducer System Datasheet
Baker Hughes document 141194 Rev. AM

APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313
EMAIL sales13@apterpower.com
WEBSITE www.apterpower.com



330101-00-19-10-02-00