

531X111PSHARG1

GE 531X power supply card

It provides the installed power-supply-card function within the configured GE 531X drive-control assembly.

IDENTITY	VALUE
Manufacturer	GE
Model	531X111PSHARG1
Product type	GE 531X power supply card
HS code	8537101190
Shipping location	Xiamen, Fujian, China

Product-specific system role

- Uses the 531X111PSHARG1 catalog identity
- Occupies the assigned 531X board position
- Interfaces through the installed power and control connectors
- Supports controlled supply and downstream-board verification

APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com



531X111PSHARG1

Technical Specifications

PARAMETER	VERIFIED VALUE
Catalog number	531X111PSHARG1
Board family	531X
Board role	Power supply

Verified system context

- GE 531X drive-control rack
- Installed board connectors
- Control-power distribution
- Approved drive configuration and wiring record

MODEL-SPECIFIC ENGINEERING NOTE

Isolate all drive power and stored energy, record connector and jumper positions, then verify supply status and downstream control-board diagnostics before enabling the drive.

System Function and Engineering Context

- Uses the 531X111PSHARG1 catalog identity
- Occupies the assigned 531X board position
- Interfaces through the installed power and control connectors
- Supports controlled supply and downstream-board verification

Companion components

- GE 531X drive-control rack
- Installed board connectors
- Control-power distribution
- Approved drive configuration and wiring record

APPLICATION	SYSTEM ROLE
Drive-control cabinet repair	Uses 531X111PSHARG1 in the documented GE 531X drive control system arrangement.
Control-power restoration	Uses 531X111PSHARG1 in the documented GE 531X drive control system arrangement.
Board-level maintenance	Uses 531X111PSHARG1 in the documented GE 531X drive control system arrangement.
Drive commissioning checks	Uses 531X111PSHARG1 in the documented GE 531X drive control system arrangement.

Installation and Commissioning Controls

1

Verify the complete 531X111PSHARG1 marking and the assigned GE 531X drive control system position before work.

2

Place the connected machine or process in the approved maintenance state before disturbing 531X111PSHARG1.

3

Isolate the applicable power and field energy, then confirm a safe state before disconnecting 531X111PSHARG1.

4

Record connector, conductor, slot and configuration identities before removal of 531X111PSHARG1.

5

Use ESD controls and protect keyed interfaces, exposed contacts and electronic assemblies during handling.

6

Confirm that the installed companion hardware and approved project match the 531X111PSHARG1 arrangement.

7

Restore power in a controlled sequence and review device, rack and host diagnostics.

8

Prove the intended function and retain the final test result before returning 531X111PSHARG1 to service.

Engineer FAQ - Part 1

What is 531X111PSHARG1?

GE 531X111PSHARG1 is ge 531x power supply card. It provides the installed power-supply-card function within the configured GE 531X drive-control assembly.

Which system uses 531X111PSHARG1?

Use 531X111PSHARG1 only in the documented GE 531X drive control system arrangement and the installed hardware configuration.

What should be checked before installing 531X111PSHARG1?

Confirm the complete marking, assigned position, companion hardware and approved configuration before field work.

How should wiring be handled when replacing 531X111PSHARG1?

Record every connector and conductor before removal, preserve polarity and shielding, and follow the applicable manufacturer connection instructions.

Engineer FAQ - Part 2

How is 531X111PSHARG1 configured after replacement?

Restore only the approved project or device settings, then verify status and diagnostics before automatic operation.

How should 531X111PSHARG1 be commissioned?

Energize under controlled conditions, exercise the intended system function and record the final diagnostic state.

What maintenance record is needed for 531X111PSHARG1?

Retain the as-found connection record, installed position, configuration revision and functional-test result.

Can 531X111PSHARG1 be substituted directly?

A substitution requires complete catalog-number, hardware-revision, interface and system-compatibility checks against the controlling documentation.

Related product pages on Apter Power

MODEL	SYSTEM ROLE	APTER POWER PAGE
ICRXIBN7M000A-BA	Related GE product	View ICRXIBN7M000A-BA page
IS200TBAIH1CCC	Related GE product	Open IS200TBAIH1CCC listing
IS200EMIOH1AFB	Related GE product	Explore IS200EMIOH1AFB module
IS400JPDHG1A	Related GE product	Review IS400JPDHG1A item
DS200SDCIG1AFB	Related GE product	See DS200SDCIG1AFB profile
UR9VM	Related GE product	Open UR9VM details
IS420YDOAS1B	Related GE product	Visit IS420YDOAS1B page
DS2020DACAG2	Related GE product	View DS2020DACAG2 option

SOURCE RECORD

General Electric drive-control maintenance documentation - GEH-5980 / 531X111PSHARG1