

130530-0050-02

legacy probe cable assembly

CONTROLLED ENGINEERING COPY

Match the complete cable tag, connector arrangement, route and companion monitoring hardware to the controlled installation drawing.

INSTALLATION IDENTITY	REQUIRED VALUE
Complete model	130530-0050-02
Manufacturer part	130530-0050-02
Hardware type	130530-0050-02
System family	Bently Nevada machinery-monitoring cabling



APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313
EMAIL sales13@apterpower.com
WEBSITE www.apterpower.com



01 PRE-INSTALLATION PLAN

- 1

Verify the complete 130530-0050-02 marking and the assigned Bently Nevada machinery-monitoring cabling position before work.
- 2

Place the connected machinery and monitoring channel in the approved maintenance state before handling 130530-0050-02.
- 3

Isolate every documented supply and field circuit before disconnecting 130530-0050-02.
- 4

Record the installed connectors, conductors, cable routing and configuration associated with 130530-0050-02.
- 5

Use ESD controls and protect exposed connectors, cable ends and keyed interfaces while handling 130530-0050-02.

MATCHED HARDWARE

- Bently Nevada machinery-monitoring cabling
- documented companion hardware
- approved field wiring or cabling
- monitoring-system configuration record

INSTALLATION CONTROL RECORD

CONTROL ITEM	REQUIRED RECORD
Identity	130530-0050-02 / 130530-0050-02 recorded
Physical interface	Bently Nevada machinery-monitoring cabling
Companion check	documented companion hardware
Functional proof	Preserves the complete cable part number
Application test	Matched transducer loop

02 WIRING & INTERFACE CHECKS

CHECK ITEM	REQUIRED VALUE
Complete model	130530-0050-02
Manufacturer	Bently Nevada
Product family	Bently Nevada machinery-monitoring cabling
Part number	130530-0050-02
Product role	Probe cable assembly
Exact option decoding	Verify against the cable tag and controlled manufacturer drawing
Companion hardware	Use only with the documented installed monitoring arrangement


SYSTEM CONNECTION RECORD

CONNECTION ITEM	DOCUMENTED ASSIGNMENT
Installed host / carrier	Bently Nevada machinery-monitoring cabling
Companion hardware	documented companion hardware
Field connection	approved field wiring or cabling
Primary system function	Preserves the complete cable part number
Controlled acceptance duty	Matched transducer loop

FIELD NOTE

Match the complete cable tag, connector arrangement, route and companion monitoring hardware to the controlled installation drawing.

03 COMMISSIONING WORKFLOW



COMMISSIONING ACCEPTANCE EVIDENCE

EVIDENCE ITEM	ACCEPTANCE CONDITION
Identity	130530-0050-02 / 130530-0050-02 recorded
Physical interface	Bently Nevada machinery-monitoring cabling
Companion check	documented companion hardware
Functional proof	Preserves the complete cable part number
Application test	Matched transducer loop

04 RETURN-TO-SERVICE RECORD

- ☐
- Confirm the documented companion hardware and ordering options for 130530-0050-02 before energizing.
- ☐
- Restore power in a controlled sequence and review monitor, rack and host diagnostics for 130530-0050-02.
- ☐
- Complete a controlled functional test and retain the final acceptance record for 130530-0050-02.
- ☐
- Confirm the intended process response before normal operation.

VERIFICATION RECORD

PRODUCT IDENTITY	130530-0050-02
INSTALLED POSITION	Documented Bently Nevada machinery-monitoring cabling position
VERIFICATION METHOD	Controlled inspection and functional test
RELEASE RECORD	Final diagnostic state retained before service

RELATED PRODUCTS ON APTER POWER

MODEL	SYSTEM ROLE	APTER POWER PAGE
Bently Nevada 21747 080 00	Related Bently Nevada machinery-monitoring product	View Bently Nevada 21747 080 00 page
Bently Nevada 21504 00 24 10 02	Related Bently Nevada machinery-monitoring product	View Bently Nevada 21504 00 24 10 02 page
Bently Nevada CB2W100 125	Related Bently Nevada machinery-monitoring product	View Bently Nevada CB2W100 125 page
Bently Nevada CB2W100 064	Related Bently Nevada machinery-monitoring product	View Bently Nevada CB2W100 064 page
Bently Nevada 146056 15 10 02 02 05	Related Bently Nevada machinery-monitoring product	View Bently Nevada 146056 15 10 02 02 05 page
Bently Nevada 146054 32 05 01 05	Related Bently Nevada machinery-monitoring product	View Bently Nevada 146054 32 05 01 05 page
Bently Nevada 146056 38 10 02 02 05	Related Bently Nevada machinery-monitoring product	View Bently Nevada 146056 38 10 02 02 05 page
Bently Nevada 146054 36 05 01 05	Related Bently Nevada machinery-monitoring product	View Bently Nevada 146054 36 05 01 05 page

SOURCE IDENTIFIERS

Approvals Quick Reference Guide and supplied manufacturer identity
108M1756; exact supplied part number

APTER POWER SALES TEAM

WHATSAPP / PHONE	+86 180 3023 5313
EMAIL	sales13@apterpower.com
WEBSITE	www.apterpower.com

