

177230-02-01-05

Seismic Transmitter

It is a 4–20 mA seismic transmitter scaled for 0–50.8 mm/s with a 10 Hz–1 kHz RMS band and multiple approvals.

Manufacturer	Bently Nevada
Product family	177230 loop-powered seismic transmitter
Complete model	177230-02-01-05
Source record	177232 Rev. T

RELATED PRODUCTS ON APTER POWER

01	Bently Nevada 330102-30-65-10-02-CN	OPEN
02	Bently Nevada 330102-40-70-10-02-CN	OPEN
03	Bently Nevada 330102-10-40-10-02-CN	OPEN
04	Bently Nevada 330102-20-55-10-02-CN	OPEN
05	Bently Nevada 330101-00-61-15-02-CN	OPEN
06	Bently Nevada 330101-00-84-20-02-CN	OPEN

APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com



177230-02-01-05

Exact-model technical record

Complete model	177230-02-01-05	Acceleration bandwidth	2.5 Hz to 10 kHz
Manufacturer	Bently Nevada	Acceleration limit	147 m/s2 (15 g) peak
Product family	177230 loop-powered seismic transmitter	Operating temperature	-40 to +85 degC
Velocity range	0 to 50.8 mm/s (0 to 2 in/s)	Housing	Hermetic 316L stainless steel
Measurement band	10 Hz to 1 kHz RMS	Connector	3-pin MIL-C-5015
Approval option	Multiple approvals	Mounting	1/4-28 UNF with documented adapters
Process output	4 to 20 mA, loop powered	Mounting torque	4 to 7 N m
Raw acceleration output	10.2 mV/m/s2 (100 mV/g), +/-20%		

OFFICIAL SOURCE COVERAGE

Source 1	177230 Seismic Transmitter Datasheet — Ordering Information, 177232 Rev. T
Source 2	177230 Seismic Transmitter Datasheet — Specifications, 177232 Rev. T
Source 3	177230 Seismic Transmitter Datasheet — Description and ordering notes, 177232 Rev. T

APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313
EMAIL sales13@apterpower.com
WEBSITE www.apterpower.com



System role and applications

Overall velocity monitoring

Publishes machine vibration velocity directly to a PLC or DCS loop.

Motor and pump monitoring

Supports permanent housing-vibration measurement on rotating assets.

Raw acceleration diagnostics

Provides the auxiliary acceleration signal for controlled diagnostic review.

Seismic transmitter renewal

Preserves range, RMS band and approval identity during replacement.

ENGINEERING BOUNDARY

Verify 177230-02-01-05, 0–50.8 mm/s loop scaling, 10 Hz–1 kHz RMS configuration, mounting adapter, cable pinout and approvals before commissioning.

RELATED PRODUCTS ON APTER POWER

01	Bently Nevada 330102-30-65-10-02-CN	OPEN
02	Bently Nevada 330102-40-70-10-02-CN	OPEN
03	Bently Nevada 330102-10-40-10-02-CN	OPEN
04	Bently Nevada 330102-20-55-10-02-CN	OPEN

APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com



Model-specific engineering questions

Q1. What velocity range is configured in Bently Nevada 177230-02-01-05?

Code 02 specifies a 0 to 50.8 mm/s (0 to 2 in/s) full-scale velocity output.

Q2. Which measurement band is used by Bently Nevada 177230-02-01-05?

Code 01 specifies 10 Hz to 1 kHz RMS processing.

Q3. What approval option belongs to Bently Nevada 177230-02-01-05?

The final 05 suffix specifies multiple approvals; the installed certification record must match the site.

Q4. What process signal is produced by Bently Nevada 177230-02-01-05?

It is a loop-powered 4–20 mA transmitter for overall seismic velocity.

SOURCE IDENTIFIER

177232 Rev. T

APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com



177230-02-01-05

Acceptance reference and related products

Q5. Which diagnostic signal is available from Bently Nevada 177230-02-01-05?

A raw acceleration output is provided at 10.2 mV/m/s2 (100 mV/g), with the specified 2.5 Hz to 10 kHz bandwidth.

Q6. What connector is fitted to Bently Nevada 177230-02-01-05?

The transmitter uses a 3-pin MIL-C-5015 connector and the mating cable must follow the specified pin assignment.

RELATED PRODUCTS ON APTER POWER

01	Bently Nevada 330101-00-61-15-02-CN	OPEN
02	Bently Nevada 330101-00-84-20-02-CN	OPEN
03	Bently Nevada 330101-00-77-15-02-CN	OPEN
04	Bently Nevada 330101-00-28-20-02-CN	OPEN
05	Bently Nevada 330101-00-66-20-02-CN	OPEN
06	Bently Nevada 330101-00-67-20-02-CN	OPEN
07	Bently Nevada 330101-00-43-15-02-CN	OPEN
08	Bently Nevada 330101-00-72-20-02-CN	OPEN
09	Bently Nevada 330101-00-75-20-02-CN	OPEN
10	Bently Nevada 330881-16-00-205-00-02	OPEN
11	Bently Nevada 330101-02-12-10-02-00	OPEN
12	Bently Nevada 3500-05-02-05-00-00-01	OPEN

APTER POWER SALES TEAM

WHATSAPP / PHONE +86 180 3023 5313
EMAIL sales13@apterpower.com
WEBSITE www.apterpower.com

