

Siemens 6DS1211-8AA

Bus Converter Power Supply

The power-supply section used in the TELEPERM M UI bus converter unit 6DS4400-8AB.

Job objective

Replace, install or verify the exact module without changing unrelated wiring, configuration, dimensions, weight or other stored product data.

Safe-work boundary

Identify Match the complete model and every suffix or secondary code.	Isolate Apply the plant-approved electrical and process isolation procedure.
Preserve Back up configuration and photograph all connections.	Control Use ESD protection and revision-controlled documentation.

Required evidence before work

Nameplate photo; slot/rack record; connector map; project backup where applicable; fault history; approved acceptance procedure.

Verification focus	
● Siemens	● 6DS1211-8AA
● TELEPERM M spare part	● Legacy replacement context

Readiness checklist

Exact identity	Siemens 6DS1211-8AA matches the work order and physical unit
System position	Rack, slot and functional assignment are recorded
Configuration	Parameters, firmware or project data are backed up when applicable
Connections	Every cable, terminal, jumper and shield is labeled
Condition	Connector, board and packaging condition are inspected
Test plan	Expected states and acceptance evidence are agreed

Interface preparation

Host unit	UI bus converter 6DS4400-8AB
Supply input	Confirm from the installed assembly and nameplate
Backplane connection	Preserve the exact slot and mating connector
Output checks	Use the converter service procedure and measured acceptance limits
Grounding	Retain the documented cabinet protective and functional earth
Status evidence	Capture pre-removal and post-startup indications

Interface acceptance record

- Host unit: UI bus converter 6DS4400-8AB
 - Backplane connection: Preserve the exact slot and mating connector
- Supply input: Confirm from the installed assembly and nameplate
 - Output checks: Use the converter service procedure and measured acceptance limits

Controlled replacement workflow

1	Confirm isolation and absence of hazardous energy
2	Compare old and replacement identities and revisions
3	Photograph and label all connections
4	Remove the existing module using ESD-safe handling
5	Inspect slot, connector, grounding and cooling path
6	Install the exact replacement without forcing connectors
7	Restore cables, jumpers and settings from the controlled record
8	Perform a final visual and continuity check before energization

STOP POINT

Do not energize if the model, slot, connector orientation, grounding, jumper state or documented system assignment is unresolved.

Configuration control	
● Host assembly: UI bus converter unit 6DS4400-8AB	● System family: TELEPERM M
● Lifecycle: Discontinued product / end of support	● Country of origin: Germany

Staged return to service

Stage	Action	Acceptance
Stage 1	Visual inspection and isolation release	Expected controlled result
Stage 2	Apply control power under observation	Expected controlled result
Stage 3	Confirm module recognition or status	Expected controlled result
Stage 4	Verify communication and affected signal paths	Expected controlled result
Stage 5	Exercise the documented function	Expected controlled result
Stage 6	Archive measured results and as-left configuration	Expected controlled result

Product-specific acceptance focus

1 Inspect backplane and connector contacts for heat or corrosion damage.	2 Avoid changing the inductive coupler or other bus-converter sections during a narrow repair.
3 Energize under observation and verify converter status before reconnecting the bus.	4 Record measured results and the as-left assembly identity.

Release evidence

- Inspect backplane and connector contacts for heat or corrosion damage.
- Energize under observation and verify converter status before reconnecting the bus.
- Avoid changing the inductive coupler or other bus-converter sections during a narrow repair.
- Record measured results and the as-left assembly identity.

Fault isolation and final record

1	Unexpected state: stop and capture evidence
2	Recheck identity, power, slot and connectors
3	Compare configuration and revision records
4	Test surrounding system before condemning the module
5	Restore a safe state and document the outcome

Apter Power handover record

Model identity	Keep the complete Siemens model code and every suffix in purchasing, installation and acceptance records.
Verification boundary	Confirm the physical nameplate, installed position and revision-controlled project documents before field work.
Apter Power support	Use the contact details and Apter Power website links in this document for product and sourcing support.

Related Apter Power products	Exact product page
Siemens 6DS1220-8AA	View Siemens 6DS1220-8AA
Siemens 6DS1223-8AA	View Siemens 6DS1223-8AA
Siemens 7UM5111-4CB01-0BB0/JJ	View Siemens 7UM5111-4CB01-0BB0/JJ
Siemens 7UT5121-4CB01-0AA0/LL	View Siemens 7UT5121-4CB01-0AA0/LL



Commissioning support sales13@apterpower.com +86 180 3023 5313 www.apterpower.com

Source and identity trace

- Exact identity: Siemens 6DS1211-8AA
- Siemens Industry Mall product record 6DS1211-8AA: power-supply section of UI bus converter unit 6DS4400-8AB