

Westinghouse 1C31192G01

Installation & Commissioning Guide

Westinghouse 1C31192G01 serves as a speed detector personality module in the Ovation I/O subsystem. It interfaces tachometer field input with 1C31189G01 speed-detector electronics module.

PRODUCT ROLE AND VERIFIED FEATURES

Feature 1

Provides one speed-sensor interface for the documented speed detector personality module function.

Feature 2

Handles tachometer field input through the specified Ovation I/O subsystem.

Feature 3

Works with 1C31189G01 speed-detector electronics module.


Feature 4

The personality module supports the terminal connection for the documented speed-detector subsystem.

VERIFIED DATA SNAPSHOT

Subsystem	Ovation speed detector
Electronics module	1C31189G01
Sensor signal	Sinusoidal or pulse-train tachometer
Measurement outputs	16-bit overspeed and 32-bit speed-regulation values

SYSTEM RELATIONSHIP



APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.



Pre-installation readiness

READINESS GATE

Identity Compare the complete marking with the approved work order and installed record.	System match Confirm the receiving channel, mating components and controlled configuration.
Physical condition Inspect mounting surfaces, connectors, terminals, cable and support hardware.	Work controls Apply authorized isolation, bypass, access and restoration procedures.

TECHNICAL PROFILE FOR THE WORK

Subsystem Ovation speed detector	Electronics module 1C31189G01
Sensor signal Sinusoidal or pulse-train tachometer	Measurement outputs 16-bit overspeed and 32-bit speed-regulation values
Input range 0.72 Hz to 65,535 Hz across the documented outputs	

IMPORTANT NOTICE

Resolve every unmatched interface, configuration or receiving-system condition before removal or installation.

SOURCE AND WORK CONTROLS

Manufacturer source	Emerson Process Management, Ovation I/O Reference Manual R3-1150 Rev 3, Section 24, February 2003.
Evidence boundary	Technical statements are limited to the identified product or applicable manufacturer family.
Selection control	Use the complete ordering string and verify the installed system before purchase or installation.

APTERPOWER SALES TEAM
WhatsApp / Phone: +86 180 3023 5313
Email: sales13@apterpower.com
Scan the approved WhatsApp code for model-specific support.



Installation sequence

CONTROLLED WORK STEPS

- 01 Match the complete 1C31192G01 marking to the work order and installed position before removal.
- 02 Confirm 1C31189G01 speed-detector electronics module before making or breaking any field connection.
- 03 Keep the assigned tachometer field input within the documented subsystem and range.
- 04 Record terminal designations, polarity, common and shield treatment before disconnecting conductors.
- 05 Inspect module seating, connector keying, terminal condition and strain relief before power is restored.
- 06 Restore the controlled channel configuration, range selection and alarm or timeout behavior after installation.
- 07 Check local indicators and controller diagnostics for internal, communication or channel faults during commissioning.
- 08 Prove the intended response across one speed-sensor interface and record the acceptance result before release.

CONNECTION RECORD

As found	Photograph and label every connection and installed orientation before removal.
Mechanical	Record mounting position, support, clearance and connector engagement.
Electrical	Record polarity, common, shield, channel assignment and cable route.
Configuration	Preserve approved settings, scaling, alarm logic and acceptance limits.
As left	Record the final physical condition and any controlled deviation.



WORK HOLD POINTS

Before removal	Identity, position, wiring, orientation and controlled settings recorded.
Before connection	Mating interfaces, condition and routing reviewed.
Before power-up	Mechanical work, wiring, shielding and configuration independently checked.
Before release	Static value, dynamic response and protection behavior accepted.

Commissioning and functional proof

COMMISSIONING SEQUENCE

Initial state Observe status at power-up and check for unexpected fault or alarm indication.	Static value Verify the expected bias, gap, loop, contact or channel value for the application.
Dynamic response Apply the approved machine or test stimulus and confirm response and scaling.	Protection path Verify the configured alarm, relay, data or receiving-system behavior.

APPLICATION-SPECIFIC EVIDENCE

Installed-base maintenance Restores the documented speed detector personality module position without changing the approved system architecture.	Loop or channel service Supports verification of tachometer field input at the assigned control-system channel.
Planned replacement Provides an exact-identity replacement path when 1C31189G01 speed-detector electronics module and the field interface have been confirmed.	Commissioning support Allows the responsible engineer to prove wiring, configuration, status and response for one speed-sensor interface.

ACCEPTANCE RECORD

Identity	Complete marking and final installed position recorded.
Physical inspection	Mounting, connectors, terminals and routing checked.
Channel status	Expected status and configured measurement confirmed.
Functional test	Required output or protection response demonstrated.
Restoration	Bypasses removed and operating state approved.

COMMISSIONING QUESTIONS

What function does Westinghouse 1C31192G01 perform?	It provides the field interface for the tachometer signal used by the 1C31189G01 Ovation speed-detector electronics module.
How many channels are associated with Westinghouse 1C31192G01?	The documented configuration provides one speed-sensor interface.

Release record and technical references

CLOSEOUT QUESTIONS

Which signal path is used by Westinghouse 1C31192G01?	It is used for tachometer field input within the specified subsystem.
Which companion hardware must be checked for Westinghouse 1C31192G01?	Confirm 1C31189G01 speed-detector electronics module and the project-specific base or terminal arrangement.
What technical values should be verified before installing Westinghouse 1C31192G01?	Verify Ovation speed detector; also confirm 1c31189g01 and every applicable range or wiring selection.
What connection details should be recorded for Westinghouse 1C31192G01?	Record terminal identifiers, polarity, common, shield termination, connector keying and the assigned channel before disconnection.
Which diagnostics should be reviewed when commissioning Westinghouse 1C31192G01?	Review the applicable power, communication, internal-fault and channel-status indications, then compare the controller status with the expected field condition.
Can a nearby ordering code replace Westinghouse 1C31192G01 without an engineering check?	No. Match the complete identifier, companion hardware, signal range, wiring and controlled project configuration before substitution.

RELATED MODELS FOR INSTALLATION PLANNING

Foxboro AD908AA FBM201	Installation-planning reference. Review the complete ordering string before selection.
Foxboro AD916AG FBM204	Installation-planning reference. Compare the required interface and system position.
Westinghouse 1C31122G01	Installation-planning reference. Confirm the execution independently for the intended task.

MANUFACTURER SOURCE AND FINAL CONTROL

Manufacturer source	Emerson Process Management, Ovation I/O Reference Manual R3-1150 Rev 3, Section 24, February 2003.
Evidence boundary	Technical statements are limited to the identified product or applicable manufacturer family.
Selection control	Use the complete ordering string and verify the installed system before purchase or installation.

IMPORTANT NOTICE

Release the equipment only after the responsible site authority accepts the recorded result.

APTERPOWER SALES TEAM
 WhatsApp / Phone: +86 180 3023 5313
 Email: sales13@apterpower.com
 Scan the approved WhatsApp code for model-specific support.

