1

01 Readiness and operating boundary

Siemens 6ES5312-5CA11 is a SIMATIC S5 IM312-5 expansion-unit interface module with a fixed 0.5 m cable for centralized connection of an EU 184U or EU 187U to an IM300-5C controller interface.

Confirm exact identity

Confirm the complete Siemens 6ES5312-5CA11 marking before work.

Exact article	6ES5312-5CA11
Interface type	IM312-5
Configuration	Centralized

Establish the safe work boundary

Place the controller and connected expansion unit in the approved maintenance state.

Identity	6ES5312-5CA11
Host	SIMATIC S5
Acceptance	Diagnostics and functional response

PAGE TRACE	REQUIRED ENTRY
Inspector	_____
Result	Pass / hold / corrective action
Record	Date, diagnostic state and release reference

CONTACT APTER POWER

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com

6ES5312-5CA11

2

02 Configuration and interface setup

Siemens 6ES5312-5CA11 carries the centralized SIMATIC S5 interface into an EU 184U or EU 187U expansion unit through its fixed 0.5 m cable.

Record the as-found configuration

Record the EU slot and paired IM300-5C controller interface.

Interface type	IM312-5
Configuration	Centralized
Installed side	Expansion unit

Map connections and settings

Protect the fixed 0.5 m cable from twisting, crushing or unapproved extension.

Identity	6ES5312-5CA11
Host	SIMATIC S5
Acceptance	Diagnostics and functional response

PAGE TRACE	REQUIRED ENTRY
Inspector	_____
Result	Pass / hold / corrective action
Record	Date, diagnostic state and release reference

CONTACT APTER POWER

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com

6ES5312-5CA11

3

03 Installation and service sequence

Siemens 6ES5312-5CA11 carries the centralized SIMATIC S5 interface into an EU 184U or EU 187U expansion unit through its fixed 0.5 m cable.

Restore the documented assembly

Confirm the receiving rack is the documented EU 184U or EU 187U.

Configuration	Centralized
Installed side	Expansion unit
Expansion units	EU 184U / EU 187U

Protect every interface

Keep the complete centralized path to the final interface within 2 m.

Identity	6ES5312-5CA11
Host	SIMATIC S5
Acceptance	Diagnostics and functional response

PAGE TRACE	REQUIRED ENTRY
Inspector	_____
Result	Pass / hold / corrective action
Record	Date, diagnostic state and release reference

CONTACT APTER POWER

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com

6ES5312-5CA11

4

04 Verification and fault isolation

Siemens 6ES5312-5CA11 carries the centralized SIMATIC S5 interface into an EU 184U or EU 187U expansion unit through its fixed 0.5 m cable.

Verify the installed function

Review controller and expansion-unit diagnostics after energization.

Installed side	Expansion unit
Expansion units	EU 184U / EU 187U
Controller-side interface	IM300-5C 6ES5300-5CA11

Isolate unexpected response

Functionally verify every affected I/O point before release.

Identity	6ES5312-5CA11
Host	SIMATIC S5
Acceptance	Diagnostics and functional response

PAGE TRACE	REQUIRED ENTRY
Inspector	_____
Result	Pass / hold / corrective action
Record	Date, diagnostic state and release reference

CONTACT APTER POWER

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com

6ES5312-5CA11

5

05 Acceptance and service handover

Siemens 6ES5312-5CA11 carries the centralized SIMATIC S5 interface into an EU 184U or EU 187U expansion unit through its fixed 0.5 m cable.

Complete the release record

Confirm the complete Siemens 6ES5312-5CA11 marking before work.

Exact article	6ES5312-5CA11
Interface type	IM312-5
Configuration	Centralized

Retain acceptance evidence

Place the controller and connected expansion unit in the approved maintenance state.

Identity	6ES5312-5CA11
Host	SIMATIC S5
Acceptance	Diagnostics and functional response

Siemens 6DD1683-0BC0

Siemens 6DD1607-0EA1

CONTACT APTER POWER

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com

6ES5312-5CA11