HIMA F-BASE RACK 01

H51X Base Rack

01 / DOCUMENTED IDENTITY AND ENGINEERING DISTINCTIONS

F-BASE RACK 01 is the H51X base-rack entry in the HIQuad X portfolio. The base-rack designation and the absence of an R suffix distinguish it from extension racks and separately listed rugged subracks.

HIQuad X platform → H51X base-rack role → F-BASE RACK 01

Application and selection

Base and extension roles differ

F-BASE RACK 01 is a base rack. The overview lists F-BASE RACK 11 and 12 as extension racks; the names must not be collapsed into one generic rack identity.

The R version is separately listed

F-BASE RACK 01 R is described as a rugged subrack. That description is not automatically a property of F-BASE RACK 01.

Rack identity does not define the complete system

The selected processor, communication hardware, power and I/O configuration require their own records. No processor speed, communication protocol or safety rating is assigned to this rack alone.

Published product facts

Assembly role	Base rack
Named host system	H51X
Catalog family	HIQuad X
Exact version	F-BASE RACK 01, without R suffix

More Apter Power catalog references

Catalog navigation only; no compatibility or substitution implied.

HIMA F3422 | View product page

HIMA F3423 | View product page

HIMA F-BASE RACK 01

H51X Base Rack

Model-specific engineering case

For a base-rack replacement in an H51X installation, preserve the exact no-R designation in the assembly list and capture the existing module-position map. An extension-rack or rugged-rack offer should be reviewed as a different assembly, even if its name begins F-BASE RACK.

Technical reference record

Technical overview | Safety platform and products, reviewed 23 October 2026 - HIQuad X section; base-rack and extension-rack rows.

Related Apter Power catalog references

Catalog navigation only. These entries do not establish compatibility, substitution or approval of a changed installation.

HIMA F3240 | View HIMA F3240 page

HIMA F6221 | View HIMA F6221 page

HIMA F3316 | View HIMA F3316 page

CONTACT APTER POWER

WHATSAPP / PHONE +86 180 3023 5313

EMAIL sales13@apterpower.com

WEBSITE www.apterpower.com

Send the exact model, quantity and requested condition for a quotation.

F-BASE RACK 01