Bently Nevada 3300/25-01-03-03-00-00-03-00

01 Product function and configuration

Exact product role

Bently Nevada 3300/25-01-03-03-00-00-03-00 applies accelerometer input conditioning for acceleration or integrated velocity to absolute housing vibration monitoring, using the exact Channel A 0–10 g pk; Channel B 0–10 g pk scale and the selected interface options.

Technical specification summary

Technical item	Specification
Measurement function	dual-channel casing vibration
Selected channel ranges	Channel A 0–10 g pk; Channel B 0–10 g pk
Input and processing	Dual accelerometer input; two acceleration channels
Channel count	2 measurement channels
Alarm relay option	Quad relay
Safety-barrier option	None
Agency approval option	None
Range multiplier	None
Acceptance method	Independent response check for channels A and B
Output verification	Indication and selected alarm path

Selected characteristics

Uses the selected Channel A 0–10 g pk; Channel B 0–10 g pk measurement range. Range and unit selection	**Accepts Dual accelerometer input; two acceleration channels.** Input compatibility
Uses quad relay alarm relay hardware. Output hardware	**Uses the base range without a multiplication option.** Interface selection

Configuration notice

Match the complete 3300/25-01-03-03-00-00-03-00 order code, input source and rear connection assembly before installation; then verify each channel through a controlled response test.

Bently Nevada 3300/25-01-03-03-00-00-03-00

02 Technical selections in context

Configured measurement path

Order-code function	Selected configuration
Measurement range	Channel A 0–10 g pk; Channel B 0–10 g pk
Input / processing	Dual accelerometer input; two acceleration channels
Alarm relay option	Quad relay
Safety-barrier option	None
Approval selection	None
Range multiplier	None

Signal-chain interpretation

The transducer, field wiring, monitor input, selected span and output path form one chain. Confirm them together when diagnosing scale, polarity, alarm or recorder discrepancies.

Technical decisions

Range suitability
Confirm Channel A 0–10 g pk; Channel B 0–10 g pk covers the intended machine behavior.

Input match
Use Dual accelerometer input; two acceleration channels and preserve its sensitivity.

Output match
Apply Quad relay relay hardware as selected.

Interface match
Apply None barrier arrangement and None multiplication.

Do not infer unspecified data

Only exact-model technical selections are stated. Installation-specific setpoints, channel destinations and machine limits must be taken from the controlled site configuration.

Bently Nevada 3300/25-01-03-03-00-00-03-00

03 Applications and commissioning logic

Application areas

Absolute Housing Vibration Monitoring
Apply the selected Channel A 0–10 g pk; Channel B 0–10 g pk span to the intended machine measurement.

Two-channel condition monitoring
Keep channel identity from the field transducer through indication and alarms.

Controlled maintenance testing
Inject or apply a known change and compare each response stage.

Protection-system integration
Verify the selected relay and barrier interface with the receiving circuit.

Commissioning logic

01	Confirm model identity and rear interface.
02	Check input family and selected range.
03	Prove channel assignment with a controlled change.
04	Test indication, recorder output and alarm behavior separately.
05	Restore normal configuration and record the result.

Selected checks

Technical check	Required value
Alarm relay option	Quad relay
Safety-barrier option	None
Agency approval option	None
Range multiplier	None
Acceptance method	Independent response check for channels A and B
Output verification	Indication and selected alarm path

Machine application

3300/25 Dual Accelerometer Monitor is used for 25-family monitoring functions represented by the selected input and range. Apply site alarm limits only after the complete response is confirmed.

Bently Nevada 3300/25-01-03-03-00-00-03-00

04 Model-specific technical questions

Questions 1–4

Why must 3300/25-01-03-03-00-00-03-00 retain its Channel A 0–10 g pk; Channel B 0–10 g pk measurement range?
The selected measurement span is Channel A 0–10 g pk; Channel B 0–10 g pk. Alarm and recorder scaling must be checked against that span rather than copied from a different range option.

Why can the wrong transducer make 3300/25-01-03-03-00-00-03-00 display a plausible value?
This configuration uses Dual accelerometer input; two acceleration channels. Preserve the transducer family, sensitivity and signal polarity as one measurement chain.

How is the selected quad relay relay hardware preserved when replacing 3300/25-01-03-03-00-00-03-00?
The selected alarm output uses quad relay relay hardware. Contact logic, energization and downstream wiring still require a functional test.

What does the unbarriered input selection require on 3300/25-01-03-03-00-00-03-00?
No safety-barrier option is selected. Do not move field conductors from a barrier-equipped circuit without an engineering review.

Selected hardware context

Item	Configuration
Measurement range	Channel A 0–10 g pk; Channel B 0–10 g pk
Input / processing	Dual accelerometer input; two acceleration channels
Alarm relay option	Quad relay
Safety-barrier option	None
Approval selection	None
Range multiplier	None

Question scope

The questions focus on the range, input and interface options in this exact model. They are not generic interchangeability claims for every monitor in the same family.

Bently Nevada 3300/25-01-03-03-00-00-03-00

05 Configuration, testing and related products

Questions 5–8

What approval assumption must be avoided with 3300/25-01-03-03-00-00-03-00?
No agency-approval option is selected in this order code. Do not infer an approval from another unit in the same monitor family.

What confirms that 3300/25-01-03-03-00-00-03-00 is operating on its unmultiplied scale?
No range multiplier is selected, so the stated scale is the active base range. A multiplied setting from another monitor must not be transferred.

How should technicians prove channel identity on 3300/25-01-03-03-00-00-03-00?
Apply a controlled input change to one identified channel at a time, then compare the local indication, buffered or recorder signal, alarm state and return to normal.

Which acceptance results should be retained for 3300/25-01-03-03-00-00-03-00?
Record the complete model, Channel A 0–10 g pk; Channel B 0–10 g pk scale, Dual accelerometer input; two acceleration channels input, relay and barrier choices, channel assignments, setpoints, delays and the observed acceptance results.

Related Bently Nevada products

Bently Nevada 330881-28-00-265-00-02

Bently Nevada 330881-28-04-265-00-02

Bently Nevada 330881-28-04-214-00-02

Bently Nevada 330901-10-60-70-02-05

Selection caution

Related links support product comparison only. Confirm input family, sensitivity, range, relay hardware, barriers and approvals for every alternative before selection.

Release criterion

Return the channel to service only after its measured response, output behavior and protection-state restoration agree with the approved machine configuration.