MVI69L-MBS

01 / Prepare the installed system

The module exchanges configured Modbus data with the CompactLogix controller through the 1769 I/O bus. An application port connects the selected serial device network, while the Ethernet connector supports configuration and diagnostic access.

Installed position

MVI69L-MBS occupies a compatible 1769 module position. The controller program, application cable and external serial devices complete the communication path.

Pre-work verification

Confirm host support

Check the controller family and project revision before adding the module; the product data sheet excludes MicroLogix 1500.

Set port jumpers

Select the electrical standard before energizing and compare the physical jumper positions with the serial cable drawing.

Check power budget

Review the installed module revision and current manual for backplane current and power-supply placement; published OEM pages differ.

Preserve the project

Archive controller tags, module configuration, station addresses, command list and port settings before removal.

Engineering checks

Why can MVI69L-MBS appear healthy while Modbus values remain stale?

The host may recognize the module even when serial framing, slave address, command schedule or register mapping disagrees with the device. Review port diagnostics and a known register exchange.

Can MVI69L-MBS be installed in a MicroLogix 1500 rack?

No. The current ProSoft product data identifies CompactLogix on the 1769 bus and explicitly excludes MicroLogix 1500; check the exact host and program revision.

MVI69L-MBS

02 / Install, commission and hand over

05 / Protect the serial network

Apply the approved isolation and termination plan for the selected RS-422/RS-485 topology; do not assume connector fit proves wiring.

06 / Commission the data path

Check front-panel status, controller recognition, diagnostic access and representative read/write values against the pre-service record.

Use one configured Modbus serial role at the application port and map only the needed device data into controller tags.

What should be captured before replacing MVI69L-MBS?

Save the controller project, module configuration, command list, device addresses, jumper positions and a baseline of diagnostic counters and representative process values.

How should conflicting power-placement figures for MVI69L-MBS be handled?

Check the installed hardware revision and the applicable ProSoft manual before calculating the 1769 power budget or slot distance; the available OEM pages state different current and placement limits.

What acceptance test should follow commissioning of MVI69L-MBS?

Confirm controller recognition, port activity and communication diagnostics, then compare expected reads and controlled writes with the device and host tag values under the site test plan.

Technical basis: ProSoft Technology MVI69L-MBS product data sheet and MVI69L-MBS User Manual.

Related product references

ProSoft MVI94-ADM

ProSoft PLX31-EIP-MBS

ProSoft MVI56-MBP

Technical enquiry

sales13@apterpower.com | +86 18030235313