Bently Nevada 84661-25

INSTALLATION AND COMMISSIONING GUIDE

Bently Nevada 84661-25 is a 25 ft armored interconnection cable for the 330500 Velomitor piezo-velocity sensor and compatible monitor wiring.

01 Job scope and safe-work boundary

The offered item is the cable assembly. Velomitor sensor, monitor and 21128 housing are separate and must be confirmed independently.

Match the complete marking	Compare 84661-25 with the installed cable and applicable Bently Nevada 330500 documentation.
Check the offered item before ordering	Request photos of 84661-25, connector, armor and terminal lugs; compare them with the installed cable and Bently Nevada documentation.

Before work starts

Identity baseline	The 84661 base number identifies the armored Velomitor cable family and 25 selects a 25 ft (approximately 7.6 m) ordered length.
Installed context	This cable carries the two-wire Velomitor signal between the 330500 sensor and monitoring terminals.
Required record	Send the complete 84661-25 marking and installed-system identifiers for technical review.
Stop condition	Stop if the complete marking, interface or approved chain cannot be matched.

Readiness data

Cable family	84661 armored interconnection cable
Ordered length	25 ft (approximately 7.6 m)
Conductors	Two-conductor, twisted, shielded
Conductor size	22 AWG
Mechanical protection	Armored cable
Sensor-end connector	Two-socket moisture-resistant female connector
Field end	Terminal lugs
Intended sensor interface	330500 Velomitor piezo-velocity sensor

02 Pre-installation readiness

Verify the full cable reference	Confirm 84661-25 and 25 ft length on the offered label.
Check sensor interface	Match the two-socket female connector to the installed 330500 sensor.
Do not use with 21128 housing	The manufacturer table identifies a different cable for that housing arrangement.
Inspect armor and route	Check bends, crushing, abrasion and transition points.
Preserve terminal mapping	Record both conductors, shield and terminal lugs before removal.
Prove the monitored channel	Verify polarity and controlled velocity response after reconnection.

Why these checks matter

Geometry	The correct thread alone does not prove case reach, target clearance or sensor calibration.
Electrical length	Match the two-socket sensor interface and field termination.
Connector ownership	Label both ends and preserve the as-found route and protector arrangement.
Approval boundary	Use the actual offered label and site classification record.
Maintenance evidence	Retain clear before-and-after photos and measured baseline values.

Planning questions

What length does the 25 suffix in 84661-25 specify?	It selects a 25 ft cable, approximately 7.6 m.
What conductor construction is used by 84661-25?	It is a two-conductor, twisted, shielded 22 AWG armored cable.
What connector is fitted to 84661-25?	The sensor end uses a moisture-resistant two-socket female connector; the field end uses terminal lugs.

Readiness decision

Marking	Keep the complete model and every suffix group in the comparison.
Installed chain	Match the two-socket sensor interface and field termination.
Acceptance	Use measured gap or channel response and retain the as-left record.

03 Replacement sequence

01 Record baseline	Photograph complete labels, position, connectors, routing and current indication.
02 Isolate	Apply the approved site isolation and machinery-protection procedure.
03 Compare	Check offered identity, geometry, cable construction and included items.
04 Install	Restore routing and interfaces from the as-found record; do not force connectors.
05 Configure	Preserve the approved monitor channel, target and system-length settings.
06 Prove	Record static indication and a controlled response in an approved machine state.
07 Handover	Archive final identity, measurements and unresolved exceptions.

Product-specific installation focus

330500 sensor interconnection	Match the moisture-resistant two-socket connector and installed sensor.
Armored cable replacement	Inspect armor, transitions and the full 25 ft route.
Monitor terminal restoration	Restore conductor, shield and terminal-lug ownership from the as-found record.
Controlled channel acceptance	Verify polarity, baseline and velocity response after installation.

Interface restoration controls

Position	Restore the documented host or machine position.
Orientation	Use the original probe, cable or sensor orientation and keying.
Cable route	Restore separation, support, bend clearance and connector protection.
Target / sensor	Keep the approved target, system length and monitor channel pairing.
Inspection	Complete visual, continuity and insulation checks before controlled energization.

Applicable technical values

Use boundary	Used with monitors
Housing boundary	Not for 21128 Velocity Transducer Housing
Family minimum length	3 ft (0.9 m)
Family maximum length	96 ft (29 m)

04 Commissioning and acceptance

Identity and fit	Compare 84661-25 with the installed cable and applicable Bently Nevada 330500 documentation.
Static baseline	Record supply and static indication before the controlled test.
Dynamic proof	Verify polarity and controlled velocity response after reconnection.
Comparison	Compare with the approved as-found or commissioning record.
Exception control	Keep every unresolved mismatch open in the maintenance record.

Fault-isolation decision path

Unexpected gap	Recheck target material, electrical length, connector engagement and channel configuration.
No channel response	Verify supply, terminal ownership and continuity before substituting another component.
Intermittent signal	Inspect connector protection, cable routing, armor transitions and vibration at the mounting point.
Scale differs	Confirm the complete matched family and sensor system length; physical fit is not calibration evidence.
Result accepted	Retain the exact model, measured baseline, test condition and as-left response.

Engineering questions

Can 84661-25 be used with a 21128 Velocity Transducer Housing?	No. The manufacturer table excludes 84661 cables from that housing arrangement.
How should polarity be preserved when replacing 84661-25?	Record both conductor destinations, shield and terminal lugs before disconnecting the old cable.
What physical damage should be checked on 84661-25?	Inspect armor, connector transition, lugs, bends, abrasion and crushing along the full route.

Acceptance evidence

Identity	Offered and removed markings plus installed position.
Interfaces	Connector, cable, target and channel ownership.
Measurements	Supply, gap, continuity and controlled response.
Handover	As-left state and unresolved exceptions.

05 Handover and field record

Why is continuity alone insufficient to accept 84661-25?	Continuity does not prove polarity, shield termination, sensor seating or monitor response.
What handover record is needed after installing 84661-25?	Keep the cable label, sensor identity, terminal map, route photos and controlled channel result.

Source and applicability

Evidence boundary	The source directly identifies the 84661 cable family, construction, length code and housing exclusion.
System matching	Sensor electrical performance is not assigned as a loose-cable rating.
Pre-purchase check	Confirm connector, 25 ft length, armor, terminal lugs and installed sensor interface.

Recommended Bently Nevada references

Bently Nevada 330101-04-36-05-02-05	Catalogue reference; verify the complete installed chain.
Bently Nevada 330102-00-32-10-02-00	Catalogue reference; verify the complete installed chain.
Bently Nevada 330909-00-30-10-02-00	Catalogue reference; verify the complete installed chain.
Bently Nevada 330180-50-CN	Catalogue reference; verify the complete installed chain.
Bently Nevada 330130-080-00-00	Catalogue reference; verify the complete installed chain.

Final record checklist

Complete identity	84661-25
Configuration	The 84661 base number identifies the armored Velomitor cable family and 25 selects a 25 ft (approximately 7.6 m) ordered length.
Final proof	Record static and controlled dynamic results with test conditions.

Discuss the complete marking with Apter Power
sales13@apterpower.com | +86 18030235313