ABB APOW-01C

Complete Product Information

ABB APOW-01C is a converter control power-supply board for the ABB ACS800-67 converter module architecture. The complete marking must be matched to the installed hardware, wiring and configuration before replacement.

01 Product identity and verified data

Complete model	APOW-01C
Product type	converter control power-supply board
Manufacturer	ABB
Technical source	ABB ACS800-67 Wind Turbine Converters Hardware Manual
Board designation	APOW-01C
ABB drawing position	A43 power-supply board position
Documented function	Converter internal control power supply
Converter family	ACS800-67 / ACS800-104 arrangements
Documented outputs	+24 V, -24 V and +12 V control rails shown in ABB circuit diagrams
Associated control board	RMIO control and I/O board in documented arrangements
Permitted combination	NRED-16 protection board with APOW-01
Alternate combination boundary	AFCB-01 pairs with APOW-11C

Engineering purpose

The complete APOW-01C identity establishes the hardware selection; installation still depends on the documented host, companion components and project configuration.

02 Additional technical specifications

Installation location	Internal converter-module assembly
Input source	Converter internal DC power path per circuit diagram
Board-level current ratings	Use exact converter circuit diagram; not inferred
Replacement boundary	Do not substitute APOW-11C without permitted protection-board combination

Evidence boundary

The exact board role and converter relationships are identified in the ABB hardware manual. Board-level electrical values not stated by ABB are not inferred.

03 Engineering overview

APOW-01C provides internal low-voltage control rails for the documented ACS800 converter arrangement. Its connector map and protection-board pairing must be captured before removal.

ABB identifies a permitted combination of NRED-16 with APOW-01, while AFCB-01 is paired with APOW-11C. Board appearance is not sufficient evidence for interchangeability.

Commissioning should measure each control rail under the approved load condition, review control-board diagnostics and confirm stable converter-ready status before enabling the power stage.

Application map

Converter control-power generation

Supply documented internal low-voltage rails to control electronics.

RMIO support

Provide control power in approved converter circuit arrangements.

Protection-board coordination

Operate only with the permitted companion-board combination.

Power-rail diagnostics

Isolate input, board and downstream-load causes of control-power faults.

Installed-chain controls

Installed drawing	Record the drawing, machine location and channel designation that govern APOW-01C.
Probe marking	Capture the complete order identity and any tag or revision visible on the delivered item.
Mechanical reference	Record thread or sleeve datum, insertion depth, lock position and expected target travel.
Cable identity	Confirm lead construction, connector condition, routing, strain relief and electrical-length relationship.
Companion electronics	Record the matching extension cable, Proximitor or signal conditioner and monitor channel.
Target condition	Confirm target material, width, runout surface and clearance from nearby conductive material.
Static baseline	Record stopped-machine gap or bias and compare it with the approved maintenance baseline.
Operating baseline	Record monitor indication and expected response after the complete channel is returned to service.

Interpretation boundaries

Probe-only limit	Do not present complete-system range, scale or linearity as a standalone output of APOW-01C.
Target influence	Material, geometry, finish and nearby conductive surfaces can change the installed response.
Length influence	Probe lead and extension cable form part of the calibrated electrical relationship.
Temperature influence	Apply component temperature limits at their actual locations and compare with process transients.
Mechanical influence	Thread engagement, rigidity, target travel and cable support affect repeatability and service life.
Acceptance rule	Use the approved machine baseline and maintenance procedure for the final as-left decision.

04 Installation and product precautions

Confirm the complete identity

Match every field of APOW-01C with the approved spare-parts record before installation.

Control electrostatic exposure

Use grounded handling, antistatic packaging and protected work surfaces for exposed electronics.

Verify the host interface

Confirm connector keying, slot assignment, supply and companion hardware before energizing.

Preserve configuration evidence

Record switches, firmware, parameters, terminal assignments and as-found diagnostics before removal.

Inspect environmental condition

Check contamination, corrosion, ventilation, vibration and cabinet temperature before fitting the replacement.

Prove the installed function

Complete the manufacturer and site acceptance procedure, then retain the as-left result with the maintenance record.

Technical notes

Installation relationship	Restore APOW-01C at the documented A43 supply position with the permitted protection-board combination and exact rail connections.
System boundary	Use only in the ABB converter configuration and connector arrangement documented for the installed unit.
Technical reference	ABB ACS800-67 Wind Turbine Converters Hardware Manual.

Controlled installation sequence

01 Isolate	Place the monitored machine and channel in the approved maintenance state; prove the required isolation.
02 Photograph	Capture APOW-01C, the installed datum, connector, route and companion-component markings.
03 Measure	Record mechanical position and the applicable stopped-machine electrical reading before removal.
04 Compare	Check delivered identity, interfaces and evidence against the approved drawing and spare-parts record.
05 Install	Fit without twisting the lead; preserve thread engagement, target clearance, bend radius and strain relief.
06 Set point	Establish the operating gap or datum only with the approved stopped-machine procedure.
07 Prove	Compare local reading, monitor indication and controlled operating response with the accepted baseline.
08 Handover	Record as-left values, photographs, deviations, responsible technician and release approval.

Engineering questions

How should the output rails of APOW-01C be checked?	Use the exact converter circuit diagram and approved test points to verify +24 V, -24 V and +12 V rails under controlled load.

Why must the protection-board identity be recorded with APOW-01C?	ABB documents permitted combinations; fitting a different supply without its matched protection board is not a like-for-like replacement.
What should be checked if one APOW-01C rail collapses under load?	Inspect the corresponding connector, downstream load, short circuit, input path and board components before replacing another control board.
What proves APOW-01C is ready for converter service?	Stable control rails, normal RMIO or control-board diagnostics and an approved converter-ready sequence are required before power-stage enable.
What evidence should be recorded before replacing APOW-01C?	Capture the complete nameplate, installed slot or mounting position, companion hardware, wiring identifiers and the accepted operating baseline for the converter control power-supply board.
How should an intermittent fault around APOW-01C be isolated?	Separate field wiring, connector, supply, grounding, configuration and host-system causes. Reproduce the symptom under a controlled test and change only one variable at a time.
What configuration evidence should be retained after commissioning APOW-01C?	Retain the hardware identity, firmware or parameter record where applicable, channel assignment, as-left measurements, alarm or diagnostic state and the approved functional-test result.
When should APOW-01C be rejected during incoming inspection?	Quarantine the item if the complete marking, connector keying, board revision, protective coating, terminal condition or required companion hardware differs from the approved replacement record.

Acceptance and support

Retain the full marking, installed-chain identities, test readings and approved machine configuration. Confirm the exact offered item and included scope in the written quotation.

Discuss the exact marking and installed application with Apter Power.
sales13@apterpower.com | +86 18030235313

Verified related product references

Related product	BCU-12 3AUA0000110430
Related product	ZINT-571 3AUA0000077333
Related product	CI858K01 3BSE018135R1
Related product	PM511V16 3BSE011181R1

Commissioning record template

Installed asset	Machine, bearing, channel or cabinet reference
Companion identities	Probe, cable, sensor, interface or monitor markings
Mechanical datum	Mounting reference, reach, alignment or sealing condition
Electrical datum	Chain length, connector, shield, supply or input assignment
Before-work baseline	Gap, bias, vibration, continuity or channel observation
As-left result	Final measured value and functional proof
Approval basis	Applicable drawing, control requirement or site procedure
Handover	Technician, date, revision and maintenance-record location

Release checklist

Identity accepted	Complete marking agrees with the order, photographs and installed asset record.
Interfaces accepted	Mechanical fit, connector, wiring and companion components match the approved design.
Environment accepted	Temperature, contamination, vibration and route protection remain inside documented limits.
Configuration accepted	Hardware assignment, chain length or supply settings agree with the installed configuration.
Static proof accepted	Gap, bias, output voltage, channel state or continuity result is recorded as applicable.
Operating proof accepted	The returned channel response agrees with the approved machine or system baseline.

As-left verification worksheet

Exact delivered marking	APOW-01C; photograph and record any additional label detail.
Installed asset reference	Machine, bearing, train, channel and drawing identifiers.
Mechanical as found	Reach, lock position, gap reference, cable route and connector support.
Static reading as found	Gap, bias, continuity or channel value appropriate to the installed system.
Companion identities	Extension cable, Proximitor or conditioner and monitor channel markings.
Mechanical as left	Final reach, lock position, target clearance and route protection.
Static reading as left	Final gap, bias, continuity or channel value with test conditions.
Operating proof	Monitor response and machine observation accepted by the responsible authority.
Deviation record	Any difference from drawing or baseline, disposition and approval reference.
Release signatures	Technician, reviewer, operations owner and date.

Escalation triggers

Identity conflict	Stop if the complete marking, suffix, revision or approval identity differs from the approved record.
Host mismatch	Escalate if the rack, carrier, backplane, terminal unit or controller assignment is not documented for APOW-01C.
Interface damage	Do not energize with bent contacts, damaged insulation, loose retainers, contamination or heat discoloration.
Environmental breach	Review any exposure beyond the documented temperature, vibration, humidity, contamination or enclosure boundary.
Unapproved substitution	Do not transfer ratings or compatibility from an adjacent order code without manufacturer evidence.
Configuration conflict	Stop if hardware settings, firmware, channel assignment or project configuration disagree with the installed record.
Unstable measurement	Investigate noise, drift, intermittent status or inconsistent readings before replacing another component.
Failed functional proof	Keep the asset in the approved maintenance state until the complete acceptance sequence is passed and recorded.

Evidence package

Nameplate evidence	Overall and close photographs showing APOW-01C, revision, approval and serial details where present.
Installation evidence	Views of the rack position, mechanical datum, terminal assignment, cable route and strain relief.
Configuration evidence	Export or screenshots identifying the approved hardware assignment and parameters without exposing credentials.
Baseline evidence	As-found readings with units, test conditions, machine state and the instrument used.
Inspection evidence	Connector, contact, insulation, fastener, contamination and heat-condition observations.
Functional evidence	As-left readings and the controlled input, output or channel response used for acceptance.
Change evidence	Any wiring, setting, firmware or mechanical change linked to its approved work reference.
Release evidence	Technician, reviewer, date, asset reference and the maintenance-record location for traceability.