Allen-Bradley 1756-IF6I

Complete Product Information

Allen-Bradley 1756-IF6I is a controllogix six-channel isolated analog input module for the ControlLogix 1756 I/O platform. The complete marking must be matched to the installed hardware, wiring and configuration before replacement.

01 Product identity and verified data

Complete model	1756-IF6I
Product type	ControlLogix six-channel isolated analog input module
Manufacturer	Allen-Bradley
Technical source	Rockwell Automation 1756-IF6I product record and publication 1756-TD002
Analog inputs	6 individually isolated
Input ranges	+/-10.5 V, 0 to 10.5 V, 0 to 5.25 V, 0 to 21 mA
Resolution	16 bit
Voltage resolution	343, 171 or 86 microV/bit by selected range
Current resolution	0.34 microA/bit
Input impedance	>10 Mohm voltage; 249 ohm current
Isolation	250 V continuous channel-to-channel and channel-to-backplane
Current draw	250 mA at 5.1 V; 100 mA at 24 V

Engineering purpose

The complete 1756-IF6I identity establishes the hardware selection; installation still depends on the documented host, companion components and project configuration.

02 Additional technical specifications

Backplane power	3.7 W
Maximum power dissipation	3.7 W voltage; 4.3 W current
Channel bandwidth	15 Hz at -3 dB
Calibrated accuracy	Better than 0.1% of range at 25 deg C
Minimum scan time	10 ms integer; 25 ms floating point
Normal-mode rejection	60 dB at 60 Hz
Common-mode rejection	120 dB at 60 Hz; 100 dB at 50 Hz
Slot width	1

Evidence boundary

Exact-model electrical values are from Rockwell Automation. Input performance depends on the configured range, terminal block, field wiring and Logix project.

03 Engineering overview

The module digitizes six independently isolated voltage or current inputs for a ControlLogix controller. Record each channel range, filter, scaling, alarm and data format before removing the original module.

The 20-pin removable terminal block, field transmitter supply and shield/reference design remain part of the measurement loop. Verify loop resistance and current-input protection before reconnecting a live transmitter.

Commissioning should inject traceable low, mid and high values on every used channel, confirm raw and engineering-unit values, and review channel alarms and open-circuit behavior in the controller tags.

Application map

Isolated process measurement

Acquire six independently isolated voltage or current loops.

Mixed-range analog monitoring

Configure each channel for the required supported signal range.

High common-mode installations

Separate channel references within the documented isolation limits.

ControlLogix retrofit

Replace an exact 1756-IF6I while preserving RTB wiring and project configuration.

Installed-chain controls

Installed drawing	Record the drawing, machine location and channel designation that govern 1756-IF6I.
Probe marking	Capture the complete order identity and any tag or revision visible on the delivered item.
Mechanical reference	Record thread or sleeve datum, insertion depth, lock position and expected target travel.
Cable identity	Confirm lead construction, connector condition, routing, strain relief and electrical-length relationship.
Companion electronics	Record the matching extension cable, Proximitor or signal conditioner and monitor channel.
Target condition	Confirm target material, width, runout surface and clearance from nearby conductive material.
Static baseline	Record stopped-machine gap or bias and compare it with the approved maintenance baseline.
Operating baseline	Record monitor indication and expected response after the complete channel is returned to service.

Interpretation boundaries

Probe-only limit	Do not present complete-system range, scale or linearity as a standalone output of 1756-IF6I.
Target influence	Material, geometry, finish and nearby conductive surfaces can change the installed response.
Length influence	Probe lead and extension cable form part of the calibrated electrical relationship.
Temperature influence	Apply component temperature limits at their actual locations and compare with process transients.
Mechanical influence	Thread engagement, rigidity, target travel and cable support affect repeatability and service life.
Acceptance rule	Use the approved machine baseline and maintenance procedure for the final as-left decision.

04 Installation and product precautions

Confirm the complete identity

Match every field of 1756-IF6I with the approved spare-parts record before installation.

Control electrostatic exposure

Use grounded handling, antistatic packaging and protected work surfaces for exposed electronics.

Verify the host interface

Confirm connector keying, slot assignment, supply and companion hardware before energizing.

Preserve configuration evidence

Record switches, firmware, parameters, terminal assignments and as-found diagnostics before removal.

Inspect environmental condition

Check contamination, corrosion, ventilation, vibration and cabinet temperature before fitting the replacement.

Prove the installed function

Complete the manufacturer and site acceptance procedure, then retain the as-left result with the maintenance record.

Technical notes

Installation relationship	Use the approved 20-pin RTB and preserve each channel's isolated field reference.
Configuration boundary	Range, filtering, real-time sampling and scaling are defined in the Logix project.
Technical reference	Rockwell Automation publication 1756-TD002 and the 1756-IF6I product record.

Controlled installation sequence

01 Isolate	Place the monitored machine and channel in the approved maintenance state; prove the required isolation.
02 Photograph	Capture 1756-IF6I, the installed datum, connector, route and companion-component markings.
03 Measure	Record mechanical position and the applicable stopped-machine electrical reading before removal.
04 Compare	Check delivered identity, interfaces and evidence against the approved drawing and spare-parts record.
05 Install	Fit without twisting the lead; preserve thread engagement, target clearance, bend radius and strain relief.
06 Set point	Establish the operating gap or datum only with the approved stopped-machine procedure.
07 Prove	Compare local reading, monitor indication and controlled operating response with the accepted baseline.
08 Handover	Record as-left values, photographs, deviations, responsible technician and release approval.

Engineering questions

How should each configured range on 1756-IF6I be documented before replacement?	Export the Logix module properties and record range, filter, real-time sampling, scaling, alarms and data format for all six channels.
What causes a current input on 1756-IF6I to read incorrectly while voltage channels remain normal?	Check the 249-ohm current path, loop supply, terminal selection, range configuration and transmitter compliance voltage.
How should isolation on 1756-IF6I be treated during field testing?	Use test equipment and wiring that preserve channel-to-channel isolation; do not create an unintended common through shields or calibrator references.
What acceptance test is appropriate for 1756-IF6I after installation?	Inject traceable low, mid and high values on every used range and compare module tags, engineering scaling, alarms and historian values.
What evidence should be recorded before replacing 1756-IF6I?	Capture the complete nameplate, installed slot or mounting position, companion hardware, wiring identifiers and the accepted operating baseline for the controllogix six-channel isolated analog input module.
How should an intermittent fault around 1756-IF6I be isolated?	Separate field wiring, connector, supply, grounding, configuration and host-system causes. Reproduce the symptom under a controlled test and change only one variable at a time.
What configuration evidence should be retained after commissioning 1756-IF6I?	Retain the hardware identity, firmware or parameter record where applicable, channel assignment, as-left measurements, alarm or diagnostic state and the approved functional-test result.
When should 1756-IF6I be rejected during incoming inspection?	Quarantine the item if the complete marking, connector keying, board revision, protective coating, terminal condition or required companion hardware differs from the approved replacement record.

Acceptance and support

Retain the full marking, installed-chain identities, test readings and approved machine configuration. Confirm the exact offered item and included scope in the written quotation.

Discuss the exact marking and installed application with Apter Power.
sales13@apterpower.com | +86 18030235313

Verified related product references

Related product	1734-EP24DC
Related product	2711-T9C1X
Related product	2711-T10C8X
Related product	1746-NIO4I

Commissioning record template

Installed asset	Machine, bearing, channel or cabinet reference
Companion identities	Probe, cable, sensor, interface or monitor markings
Mechanical datum	Mounting reference, reach, alignment or sealing condition
Electrical datum	Chain length, connector, shield, supply or input assignment
Before-work baseline	Gap, bias, vibration, continuity or channel observation
As-left result	Final measured value and functional proof
Approval basis	Applicable drawing, control requirement or site procedure
Handover	Technician, date, revision and maintenance-record location

Release checklist

Identity accepted	Complete marking agrees with the order, photographs and installed asset record.
Interfaces accepted	Mechanical fit, connector, wiring and companion components match the approved design.
Environment accepted	Temperature, contamination, vibration and route protection remain inside documented limits.
Configuration accepted	Hardware assignment, chain length or supply settings agree with the installed configuration.
Static proof accepted	Gap, bias, output voltage, channel state or continuity result is recorded as applicable.

Operating proof accepted	The returned channel response agrees with the approved machine or system baseline.

As-left verification worksheet

Exact delivered marking	1756-IF6I; photograph and record any additional label detail.
Installed asset reference	Machine, bearing, train, channel and drawing identifiers.
Mechanical as found	Reach, lock position, gap reference, cable route and connector support.
Static reading as found	Gap, bias, continuity or channel value appropriate to the installed system.
Companion identities	Extension cable, Proximitor or conditioner and monitor channel markings.
Mechanical as left	Final reach, lock position, target clearance and route protection.
Static reading as left	Final gap, bias, continuity or channel value with test conditions.
Operating proof	Monitor response and machine observation accepted by the responsible authority.
Deviation record	Any difference from drawing or baseline, disposition and approval reference.
Release signatures	Technician, reviewer, operations owner and date.

Escalation triggers

Identity conflict	Stop if the complete marking, suffix, revision or approval identity differs from the approved record.
Host mismatch	Escalate if the rack, carrier, backplane, terminal unit or controller assignment is not documented for 1756-IF6I.
Interface damage	Do not energize with bent contacts, damaged insulation, loose retainers, contamination or heat discoloration.
Environmental breach	Review any exposure beyond the documented temperature, vibration, humidity, contamination or enclosure boundary.
Unapproved substitution	Do not transfer ratings or compatibility from an adjacent order code without manufacturer evidence.
Configuration conflict	Stop if hardware settings, firmware, channel assignment or project configuration disagree with the installed record.
Unstable measurement	Investigate noise, drift, intermittent status or inconsistent readings before replacing another component.
Failed functional proof	Keep the asset in the approved maintenance state until the complete acceptance sequence is passed and recorded.

Evidence package

Nameplate evidence	Overall and close photographs showing 1756-IF6I, revision, approval and serial details where present.
Installation evidence	Views of the rack position, mechanical datum, terminal assignment, cable route and strain relief.
Configuration evidence	Export or screenshots identifying the approved hardware assignment and parameters without exposing credentials.
Baseline evidence	As-found readings with units, test conditions, machine state and the instrument used.
Inspection evidence	Connector, contact, insulation, fastener, contamination and heat-condition observations.
Functional evidence	As-left readings and the controlled input, output or channel response used for acceptance.
Change evidence	Any wiring, setting, firmware or mechanical change linked to its approved work reference.
Release evidence	Technician, reviewer, date, asset reference and the maintenance-record location for traceability.