Bently Nevada 330105-02-12-05-02-00

Engineering Installation, Diagnostic and Acceptance Guide

Bently Nevada 330105-02-12-05-02-00 is a reverse mount 3300 XL 8 mm proximity probe configured with 3/8-24 UNF-2A, 0.5 m integral lead and miniature clickloc coaxial connector. It is the passive sensing element in a matched non-contact vibration and position measurement chain.

01 Work package

Complete model	330105-02-12-05-02-00
Product type	3300 XL 8 mm Proximity Probe
Manufacturer	Bently Nevada
Supply condition	New, original product
Technical source	Bently Nevada 3300 XL 8 mm Proximity Transducer System Datasheet, 141194 Rev. AL

Field decisions

1 Establish identity

Capture the full marking, installed companion components and baseline before disconnection.

2 Inspect interfaces

Verify mounting, cable, connector, armor, approval and environmental boundaries.

3 Fit the exact chain

Preserve the documented probe-cable-Proximitor or sensor-monitor relationship.

4 Prove response

Use the approved stopped-machine and operating acceptance procedure.

5 Record as left

Save markings, configuration, test values and operating observations.

02 Interface and configuration map

Product type	Reverse-mount 3300 XL 8 mm proximity probe
Mounting arrangement	reverse mount
Case thread	3/8-24 UNF-2A
Armor	Stainless-steel armor
Unthreaded length	fixed reverse-mount geometry
Overall case length	fixed reverse-mount geometry
Integral lead length	0.5 m

Connector	Miniature ClickLoc coaxial connector
Cable option	Standard cable
Agency approval option	Not required
Probe family	3300 XL 8 mm proximity transducer system
Probe tip material	Polyphenylene sulfide (PPS)
Probe case material	AISI 304 stainless steel
Cable construction	75 ohm triaxial cable with FEP insulation
Connector material	Gold-plated brass miniature coaxial ClickLoc
Matched-system linear range	2.0 mm under the stated target and calibration conditions
Matched-system scale factor	7.87 V/mm (200 mV/mil) under the stated conditions
Matched-system frequency response	0 to 10 kHz typical
Reference target	AISI 4140 steel unless the installation is separately characterized
System-length rule	Probe lead plus extension cable must match the selected 5 m or 9 m Proximitor system

03 Installation workflow

Confirm the complete marking

Match every field of 330105-02-12-05-02-00 with the installed record before removal or installation.

Protect the sensing tip

Keep the PPS tip away from impact, metal chips and solvents not approved for the installed procedure.

Control installation torque

Use the probe-family wrench flats and approved thread procedure; do not transmit torque through the cable.

Preserve the coaxial path

Keep ClickLoc contacts clean, aligned and dry, and protect the connection from cable strain.

Set the operating gap

Establish gap from the approved stopped-machine procedure and confirm target travel remains within the working region.

Prove the complete channel

Verify gap voltage, monitor indication and operating response before returning protection or monitoring to service.

Application checks

Radial shaft vibration

Use the installed probe at the approved bearing location to observe shaft motion relative to the probe mounting.

Axial position

Apply the probe to a conductive thrust target only when the target travel remains inside the calibrated working region.

Speed or phase reference

Use an approved target feature and monitor configuration when the channel provides a once-per-turn reference.

Probe replacement

Retain thread, reach, lead, connector, approval and total-system length when replacing the installed sensing element.

04 Diagnostic decision table

How should the sleeve and reverse-mount position of 330105-02-12-05-02-00 be documented before removal?	Record the sleeve reference, retained hardware, cable exit, stopped-machine gap voltage and insertion relationship. Rebuild the same mechanical datum before setting the final electrical gap.
What confirms that 330105-02-12-05-02-00 is connected to the correct 5 m channel?	Trace the 0.5 m probe lead and extension cable to the Proximitor Sensor, then verify their combined length and sensor marking against the approved loop record.
How can connector contamination affect 330105-02-12-05-02-00 during commissioning?	Moisture or conductive debris changes the coaxial impedance and may shift gap voltage or noise. Inspect, clean and fully seat the ClickLoc connection before diagnosing the probe.
Why should the FluidLoc option not be assumed for 330105-02-12-05-02-00?	This order code selects the standard cable and the reverse-mount probe sleeve normally provides the intended protection. Compare the actual environment and marking before specifying a different cable construction.

Release review

Installation relationship	Use the 3/8-24 UNF-2A mounting and the documented fixed reverse-mount geometry / fixed reverse-mount geometry geometry to establish the approved installed position.
System boundary	Treat range, scale factor and frequency response as complete-chain values, not standalone probe output ratings.
Technical reference	Bently Nevada 3300 XL 8 mm Proximity Transducer System Datasheet, 141194 Rev. AL.

Engineering questions

How should the sleeve and reverse-mount position of 330105-02-12-05-02-00 be documented before removal?	Record the sleeve reference, retained hardware, cable exit, stopped-machine gap voltage and insertion relationship. Rebuild the same mechanical datum before setting the final electrical gap.
What confirms that 330105-02-12-05-02-00 is connected to the correct 5 m channel?	Trace the 0.5 m probe lead and extension cable to the Proximitor Sensor, then verify their combined length and sensor marking against the approved loop record.
How can connector contamination affect 330105-02-12-05-02-00 during commissioning?	Moisture or conductive debris changes the coaxial impedance and may shift gap voltage or noise. Inspect, clean and fully seat the ClickLoc connection before diagnosing the probe.
Why should the FluidLoc option not be assumed for 330105-02-12-05-02-00?	This order code selects the standard cable and the reverse-mount probe sleeve normally provides the intended protection. Compare the actual environment and marking before specifying a different cable construction.
What gap checks are needed after reinstalling 330105-02-12-05-02-00?	With the machine in the approved stopped condition, restore the mechanical reference, measure gap voltage and confirm expected target travel remains inside the channel's calibrated region.
How should a noisy channel using 330105-02-12-05-02-00 be isolated?	Separate mechanical looseness, target runout, connector contamination and cable routing from monitor faults. Compare stopped-machine noise and substitution results only with a verified matched component.

Can 330105-02-12-05-02-00 be exchanged with a standard-mount probe?	Not on order-code similarity alone. Reverse-mount hardware, sleeve geometry, cable route and the approved installed drawing must all support the proposed change.
What evidence should close a replacement of 330105-02-12-05-02-00?	Retain the full marking, sleeve and mounting record, connector inspection, total-system-length check, stopped-machine gap and operating channel response.

Acceptance and support

Retain the full marking, installed-chain identities, test readings and approved machine configuration. Confirm the exact offered item and included scope in the written quotation.

Discuss the exact marking and installed application with Apter Power.
sales13@apterpower.com | +86 18030235313

Verified related product references

Related product	330500-00-01
Related product	330980-70-CN
Related product	330930-040-03-00
Related product	84661-96

Commissioning record template

Installed asset	Machine, bearing, channel or cabinet reference
Companion identities	Probe, cable, sensor, interface or monitor markings
Mechanical datum	Mounting reference, reach, alignment or sealing condition
Electrical datum	Chain length, connector, shield, supply or input assignment
Before-work baseline	Gap, bias, vibration, continuity or channel observation
As-left result	Final measured value and functional proof
Approval basis	Applicable drawing, control requirement or site procedure
Handover	Technician, date, revision and maintenance-record location

Handover note

A replacement is complete only after the installed identity, physical interfaces, measured response and configuration record agree. Escalate any mismatch before the channel returns to protection or monitoring service.