Yokogawa AAB841

Complete Product Information

Yokogawa AAB841 is a 8-channel voltage-input/current-output analog I/O module. Its exact marking, installed interfaces and companion equipment must be verified before replacement or commissioning.

01 Product identity and verified data

Complete model	AAB841
Product type	8-channel voltage-input/current-output analog I/O module
Manufacturer	Yokogawa
Supply condition	New, original product
Technical source	Yokogawa GS 33K50F60-50E Analog Input/Output Modules
I/O channel count	8 inputs and 8 outputs
Channel isolation	Non-isolated; differential voltage inputs
Input signal	1 to 5 V DC
Output signal	4 to 20 mA DC
Allowable common-mode voltage	±1 V or less
Allowable input voltage	±7.5 V
Input resistance, powered	1 MΩ or greater
Input resistance, power off	340 kΩ or greater

Engineering purpose

The complete AAB841 identity establishes the offered hardware. Confirm the installed system, revision and field interfaces before approving the replacement.

02 Additional technical specifications

Allowable output load	0 to 750 Ω
Output open-circuit detection	Less than 0.65 mA
Input accuracy	±4 mV
Output accuracy	±48 µA
Data update period	10 ms
Input step response	100 ms
Output step response	40 ms
Maximum consumption	310 mA at 5 V DC and 250 mA at 24 V DC
Manufacturer module size	32.8 mm x 107.5 mm x 130 mm
Manufacturer module weight	0.3 kg

Evidence boundary

Exact-model values are taken from the Yokogawa AAB841 column; adjacent AAB842 current-input values are not transferred.

03 Engineering overview

AAB841 combines eight 1 to 5 V differential inputs with eight 4 to 20 mA outputs for loop-by-loop analog processing in compatible Yokogawa field-control hardware.

The module is non-isolated, so common-mode voltage, field commons and shield routing must be reviewed as a complete installation. Output load and open-circuit behaviour should be checked at the terminal interface.

A controlled replacement preserves slot, redundancy assignment, cable type, database channel mapping and loop calibration. Acceptance should exercise both the input measurement and associated output path for each used channel.

Application map

Analog loop concentration

Acquire eight 1 to 5 V signals and drive eight 4 to 20 mA outputs.

Control-loop migration

Maintain ST/RIO replacement wiring through the approved Yokogawa interface arrangement.

Redundant field I/O

Apply the module only in a manufacturer-supported redundant configuration.

Loop troubleshooting

Separate field-signal, load, cable and channel-assignment faults with measured evidence.

04 Installation and product precautions

Save channel mapping

Export or record every used input and output assignment before removal.

Check common-mode voltage

Measure field commons and keep differential input common mode within the documented limit.

Confirm load resistance

Calculate total output-loop resistance and verify it is within 0 to 750 Ω.

Preserve cable identity

Match the installed KS, MIL or pressure-clamp interface to the approved drawing.

Prove both directions

Test input scaling and output response independently for every commissioned loop.

Record redundancy state

Confirm the approved single or redundant module arrangement before return to service.

Technical notes

Installation relationship	Use the exact model marking and manufacturer wiring or installation information for the delivered hardware.
System boundary	Verify host equipment, companion interfaces, field wiring and configuration before energizing.
Technical reference	Yokogawa GS 33K50F60-50E Analog Input/Output Modules.

Engineering questions

How should common-mode voltage be checked on AAB841?	Measure each input conductor relative to the system reference under operating conditions and confirm the resulting common-mode component remains within ±1 V.
What output-loop test best proves AAB841 after replacement?	Command low, mid and high values, measure loop current at the field boundary, and compare indication, load response and open-circuit detection.
How can input and output faults be separated on AAB841?	Inject a traceable 1 to 5 V test signal at the input while independently driving the 4 to 20 mA output, then compare raw values, engineering units and field measurements.
What resistance calculation is required for each AAB841 output?	Add cable resistance, receiver input resistance and barriers or isolators; the total must remain inside the 0 to 750 Ω range.
How should redundancy be verified for AAB841?	Confirm the supported redundant base, module pairing, control database and switchover procedure, then prove both active and standby paths without disturbing unrelated loops.
What evidence is needed before moving an AAB841 cable assembly?	Record cable part number, connector orientation, channel schedule, field terminal references and shield termination before disconnection.
How should the 10 ms update period of AAB841 be considered?	Evaluate it together with the 100 ms input and 40 ms output step responses and the control-loop dynamics; do not treat update period alone as total response time.
What as-left data should be stored for AAB841?	Retain channel mapping, common-mode measurements, loop resistance, input/output calibration points, redundancy result and any database changes.

Acceptance and support

Retain the full marking, installed-chain identities, test readings and approved machine configuration. Confirm the exact offered item and included scope in the written quotation.

Discuss the exact marking and installed application with Apter Power.
sales13@apterpower.com | +86 18030235313

Verified related product references

Related product	AAI841-H00
Related product	ADV159-P00
Related product	SDV144-S33
Related product	CP461-10

Commissioning record template

Installed asset	Machine, bearing, channel or cabinet reference
Companion identities	Probe, cable, sensor, interface or monitor markings
Mechanical datum	Mounting reference, reach, alignment or sealing condition
Electrical datum	Chain length, connector, shield, supply or input assignment
Before-work baseline	Gap, bias, vibration, continuity or channel observation
As-left result	Final measured value and functional proof
Approval basis	Applicable drawing, control requirement or site procedure
Handover	Technician, date, revision and maintenance-record location

Handover note

A replacement is complete only after the installed identity, physical interfaces, measured response and configuration record agree. Escalate any mismatch before the channel returns to protection or monitoring service.

Release checklist

Identity accepted	Complete marking agrees with the order, photographs and installed asset record.
Interfaces accepted	Mechanical fit, connector, wiring and companion components match the approved design.
Environment accepted	Temperature, contamination, vibration and route protection remain inside documented limits.
Configuration accepted	Hardware assignment, chain length or supply settings agree with the installed configuration.
Static proof accepted	Gap, bias, output voltage, channel state or continuity result is recorded as applicable.
Operating proof accepted	The returned channel response agrees with the approved machine or system baseline.

Verification record and related references

Nameplate evidence Full marking, suffix and revision photographs	Related reference SDV144-S33
Interface evidence Connector, mounting and companion-hardware record	Related reference CP461-10
Measured evidence Supply, signal, load or continuity result	Related reference S9400UK
Release evidence As-left result, reviewer and return-to-service date	Related reference AAB841