General Electric IS420ESWBH3AX

Complete Product Information

General Electric IS420ESWBH3AX is a mark vie 16-port copper ionet ethernet switch for the Mark VIe / Mark VIeS IONet architecture. The complete marking must be matched to the installed hardware, wiring and configuration before replacement.

01 Product identity and verified data

Complete model	IS420ESWBH3AX
Product type	Mark VIe 16-port copper IONet Ethernet switch
Manufacturer	General Electric
Technical source	GE Mark VIeS functional-safety material and IS420ESWBH3A KC registration
Base hardware identity	IS420ESWBH3A
Delivered marking	IS420ESWBH3AX
Network role	Mark VIe IONet switch
Copper Ethernet ports	16
Fiber ports	None for H3A base selection
Connector family	RJ-45 copper IONet ports
Mounting	DIN-rail with the approved mounting base or clip
Cooling	Convection cooled

Engineering purpose

The complete IS420ESWBH3AX identity establishes the hardware selection; installation still depends on the documented host, companion components and project configuration.

02 Additional technical specifications

Safety-system role	Non-interfering network component in approved Mark VIeS designs
Network medium	Category 5e copper Ethernet cabling in the documented system
Configuration boundary	Port assignments and redundancy follow the Mark VIe project drawing
Suffix control	Confirm X suffix meaning from delivered label and GE project documentation

Evidence boundary

The official record establishes IS420ESWBH3A as a 16-port no-fiber IONet switch. The delivered X suffix must be confirmed from the complete nameplate and project record.

03 Engineering overview

The ESWB H3A base hardware provides sixteen copper IONet connections for Mark VIe and approved Mark VIeS control arrangements. The full IS420ESWBH3AX label and installed port map should be captured before disconnection.

IONet traffic belongs to the turbine-control architecture rather than a general office network. Preserve cable labels, redundant path separation, controller ownership and I/O-pack connections exactly as shown on the project drawing.

Commissioning should verify both power inputs where fitted, port link indications, controller-to-I/O communication and network diagnostics. Unused ports, cabinet grounding and cable routing must remain consistent with the approved enclosure design.

Application map

Mark VIe IONet distribution

Connect controllers and I/O packs over the approved deterministic control network.

Copper network expansion

Provide sixteen RJ-45 connections where the project requires no fiber interface.

Redundant control paths

Maintain physically and logically separated IONet paths in approved architectures.

Turbine-control retrofit

Replace an exact ESWB assembly while preserving the project port map and cabling.

Installed-chain controls

Installed drawing	Record the drawing, machine location and channel designation that govern IS420ESWBH3AX.
Probe marking	Capture the complete order identity and any tag or revision visible on the delivered item.
Mechanical reference	Record thread or sleeve datum, insertion depth, lock position and expected target travel.
Cable identity	Confirm lead construction, connector condition, routing, strain relief and electrical-length relationship.
Companion electronics	Record the matching extension cable, Proximitor or signal conditioner and monitor channel.
Target condition	Confirm target material, width, runout surface and clearance from nearby conductive material.
Static baseline	Record stopped-machine gap or bias and compare it with the approved maintenance baseline.
Operating baseline	Record monitor indication and expected response after the complete channel is returned to service.

Interpretation boundaries

Probe-only limit	Do not present complete-system range, scale or linearity as a standalone output of IS420ESWBH3AX.
Target influence	Material, geometry, finish and nearby conductive surfaces can change the installed response.
Length influence	Probe lead and extension cable form part of the calibrated electrical relationship.
Temperature influence	Apply component temperature limits at their actual locations and compare with process transients.
Mechanical influence	Thread engagement, rigidity, target travel and cable support affect repeatability and service life.
Acceptance rule	Use the approved machine baseline and maintenance procedure for the final as-left decision.

04 Installation and product precautions

Confirm the complete identity

Match every field of IS420ESWBH3AX with the approved spare-parts record before installation.

Control electrostatic exposure

Use grounded handling, antistatic packaging and protected work surfaces for exposed electronics.

Verify the host interface

Confirm connector keying, slot assignment, supply and companion hardware before energizing.

Preserve configuration evidence

Record switches, firmware, parameters, terminal assignments and as-found diagnostics before removal.

Inspect environmental condition

Check contamination, corrosion, ventilation, vibration and cabinet temperature before fitting the replacement.

Prove the installed function

Complete the manufacturer and site acceptance procedure, then retain the as-left result with the maintenance record.

Technical notes

Installation relationship	Preserve the exact cabinet location, mounting base, power wiring and sixteen-port network map.
Network boundary	Use only within the approved Mark VIe or Mark VIeS IONet architecture and project cabling design.
Technical reference	GE Mark VIeS functional-safety material and IS420ESWBH3A KC registration.

Controlled installation sequence

01 Isolate	Place the monitored machine and channel in the approved maintenance state; prove the required isolation.
02 Photograph	Capture IS420ESWBH3AX, the installed datum, connector, route and companion-component markings.
03 Measure	Record mechanical position and the applicable stopped-machine electrical reading before removal.
04 Compare	Check delivered identity, interfaces and evidence against the approved drawing and spare-parts record.
05 Install	Fit without twisting the lead; preserve thread engagement, target clearance, bend radius and strain relief.
06 Set point	Establish the operating gap or datum only with the approved stopped-machine procedure.
07 Prove	Compare local reading, monitor indication and controlled operating response with the accepted baseline.
08 Handover	Record as-left values, photographs, deviations, responsible technician and release approval.

Engineering questions

How should every cable on IS420ESWBH3AX be documented before replacement?	Photograph both ends, record port numbers, controller or I/O-pack destinations, redundant-network identity and cabinet route before unplugging any RJ-45 connector.

What should be checked if one port on IS420ESWBH3AX has no link after replacement?	Confirm the port map, cable continuity, mating device power, connector condition and the assigned network path before moving the cable to another port.
How should redundant IONet paths through IS420ESWBH3AX be proved?	Use the approved turbine-control procedure to verify each path separately while monitoring controller and I/O-pack diagnostics for loss or recovery events.
Why must the X suffix on IS420ESWBH3AX remain in the maintenance record?	It is part of the delivered marking; do not collapse it to the H3A base identity until GE project documentation establishes equivalence.
What evidence should be recorded before replacing IS420ESWBH3AX?	Capture the complete nameplate, installed slot or mounting position, companion hardware, wiring identifiers and the accepted operating baseline for the mark vie 16-port copper ionet ethernet switch.
How should an intermittent fault around IS420ESWBH3AX be isolated?	Separate field wiring, connector, supply, grounding, configuration and host-system causes. Reproduce the symptom under a controlled test and change only one variable at a time.
What configuration evidence should be retained after commissioning IS420ESWBH3AX?	Retain the hardware identity, firmware or parameter record where applicable, channel assignment, as-left measurements, alarm or diagnostic state and the approved functional-test result.
When should IS420ESWBH3AX be rejected during incoming inspection?	Quarantine the item if the complete marking, connector keying, board revision, protective coating, terminal condition or required companion hardware differs from the approved replacement record.

Acceptance and support

Retain the full marking, installed-chain identities, test readings and approved machine configuration. Confirm the exact offered item and included scope in the written quotation.

Discuss the exact marking and installed application with Apter Power.
sales13@apterpower.com | +86 18030235313

Verified related product references

Related product	DS3800HCMC1A1B
Related product	DS200DSPCH1AEA
Related product	IS220PTURH1A
Related product	531X133PRUALG1

Commissioning record template

Installed asset	Machine, bearing, channel or cabinet reference
Companion identities	Probe, cable, sensor, interface or monitor markings
Mechanical datum	Mounting reference, reach, alignment or sealing condition
Electrical datum	Chain length, connector, shield, supply or input assignment
Before-work baseline	Gap, bias, vibration, continuity or channel observation
As-left result	Final measured value and functional proof
Approval basis	Applicable drawing, control requirement or site procedure
Handover	Technician, date, revision and maintenance-record location

Release checklist

Identity accepted	Complete marking agrees with the order, photographs and installed asset record.
Interfaces accepted	Mechanical fit, connector, wiring and companion components match the approved design.
Environment accepted	Temperature, contamination, vibration and route protection remain inside documented limits.
Configuration accepted	Hardware assignment, chain length or supply settings agree with the installed configuration.
Static proof accepted	Gap, bias, output voltage, channel state or continuity result is recorded as applicable.
Operating proof accepted	The returned channel response agrees with the approved machine or system baseline.

As-left verification worksheet

Exact delivered marking	IS420ESWBH3AX; photograph and record any additional label detail.
Installed asset reference	Machine, bearing, train, channel and drawing identifiers.
Mechanical as found	Reach, lock position, gap reference, cable route and connector support.
Static reading as found	Gap, bias, continuity or channel value appropriate to the installed system.
Companion identities	Extension cable, Proximitor or conditioner and monitor channel markings.
Mechanical as left	Final reach, lock position, target clearance and route protection.
Static reading as left	Final gap, bias, continuity or channel value with test conditions.
Operating proof	Monitor response and machine observation accepted by the responsible authority.
Deviation record	Any difference from drawing or baseline, disposition and approval reference.
Release signatures	Technician, reviewer, operations owner and date.

Escalation triggers

Identity conflict	Stop if the complete marking, suffix, revision or approval identity differs from the approved record.
Host mismatch	Escalate if the rack, carrier, backplane, terminal unit or controller assignment is not documented for IS420ESWBH3AX.
Interface damage	Do not energize with bent contacts, damaged insulation, loose retainers, contamination or heat discoloration.
Environmental breach	Review any exposure beyond the documented temperature, vibration, humidity, contamination or enclosure boundary.
Unapproved substitution	Do not transfer ratings or compatibility from an adjacent order code without manufacturer evidence.
Configuration conflict	Stop if hardware settings, firmware, channel assignment or project configuration disagree with the installed record.
Unstable measurement	Investigate noise, drift, intermittent status or inconsistent readings before replacing another component.
Failed functional proof	Keep the asset in the approved maintenance state until the complete acceptance sequence is passed and recorded.

Evidence package

Nameplate evidence	Overall and close photographs showing IS420ESWBH3AX, revision, approval and serial details where present.
Installation evidence	Views of the rack position, mechanical datum, terminal assignment, cable route and strain relief.
Configuration evidence	Export or screenshots identifying the approved hardware assignment and parameters without exposing credentials.
Baseline evidence	As-found readings with units, test conditions, machine state and the instrument used.
Inspection evidence	Connector, contact, insulation, fastener, contamination and heat-condition observations.
Functional evidence	As-left readings and the controlled input, output or channel response used for acceptance.
Change evidence	Any wiring, setting, firmware or mechanical change linked to its approved work reference.
Release evidence	Technician, reviewer, date, asset reference and the maintenance-record location for traceability.