



T9300

AADvance Three-way I/O Base Unit



INSTALLATION AND COMMISSIONING WORKBOOK

1

IDENTIFY

2

ISOLATE

3

INSTALL

4

VERIFY

Preparation gate

Complete these checks before disconnecting the installed product.

1	Confirm T9300 and the planned three I/O positions before mounting.	☐
2	Isolate controller power before joining or separating base units.	☐
3	Verify DIN-rail or panel fixings and the plastic retaining clip.	☐
4	Inspect left and right bus connectors for damage or contamination.	☐

PRE-WORK RECORD

Work order	_____	Drawing / revision	_____
Checked by	_____	Date	_____

Installation and connection sequence

Mount T9300 on the approved DIN rail or panel and clip adjacent base units together before fitting termination assemblies or I/O modules. Verify the left and right bus connectors, retaining clip, power path and Workbench hardware order before applying controller power.

05

Plan termination-assembly widths and any bridging before inserting modules.

06

Confirm the T9100/T9310 connection path and bus number.

07

Update the AADvance Workbench hardware tree under the approved procedure.

08

Power up under control and verify recognition and diagnostics for every fitted module.

Commissioning record

Record the controlled checks used to release this exact product.

1. Identity / article	PASS / FAIL	_____

2. Mechanical installation	PASS / FAIL	_____

3. Power / wiring	PASS / FAIL	_____

4. Grounding / shielding	PASS / FAIL	_____

5. Configuration	PASS / FAIL	_____

6. Signal response	PASS / FAIL	_____

7. Diagnostics / alarms	PASS / FAIL	_____

8. Final release	PASS / FAIL	_____

MODEL-SPECIFIC ACCEPTANCE

Confirm T9300 identity, mounting method, T9100 processor-base connection, T9310 expansion cable where used, bus number, adjacent retaining clips, termination-assembly grouping, module order, Workbench release and full I/O recognition before commissioning.

Engineering navigation and closeout

Eight different validated product pages for related system planning.

VALIDATED RELATED ENGINEERING PAGES	
01	TC-301-02-2M0 Apter Power product page
02	TC-301-02-6M5 Apter Power product page
03	TC-301-02-10M0 Apter Power product page
04	T9482 Apter Power product page
05	T9803 Apter Power product page
06	TC-001-02-2M5 Apter Power product page
07	T8235 Apter Power product page
08	TC-301-02-15M0 Apter Power product page

Navigation links only - not manufacturer evidence for technical parameters.

MANUFACTURER SOURCE

AADvance Controller Solutions Handbook | ICSTT-RM447N-EN-P, February 2021

APTER POWER SALES TEAM

WHATSAPP / PHONE

+86 180 3023 5313

EMAIL

sales13@apterpower.com

WEBSITE

www.apterpower.com



T9300